Kollmorgen Essentials Drive

3, 6, 12 Amp Single-Axis Servo Drive with Functional Safety Option 1, STO - SIL2

Installation Manual, English



Manual Edition: A, October 2025 Safety Edition: A, September 2025

Valid for Kollmorgen Essentials Drive Hardware Revision AA

Part Number: 903-700004-00 HTS Code: 8504.40.4000

Original Document



For safe and proper use, follow these instructions. Keep for future use.









Record of Document Revisions

Edition	Remarks
A, 10/2025	First edition
	Table with lifecycle information of this document (→ # 136)

Hardware Revision (HR)

Kollmorgen Essentials Drive	Firmware	WorkBench	KAS-IDE	Remarks
AA	02-15-00-001	from 2.19.0.11848	4.04 R1	First revision

Current patents

- US Patent 81,542,28 (Dynamic Braking For Electric Motors)
- US Patent 10,374,468 (System and method for improved DC power line communication)
- US Patent 10,520,050 (Method and apparatus for power-saving, fail-safe control of an electromechanical brake)
- US Patent 10,840,696 (Method and apparatus for limiting the output voltages of switch mode power supplies)

Patents referring to fieldbus functions are listed in the matching fieldbus manual.

Table of Contents

Т	ble of Contents	3
1	Welcome to Kollmorgen Essentials	7
2	General	8
	2.1 About this Installation Manual	9
	2.2 Symbols Used	10
	2.2.1 Warning Symbols	10
	2.2.2 Drawing Symbols	11
	2.3 Abbreviations Used	12
3	Product Safety	14
	3.1 You should pay attention to this	
	3.2 Use as Directed	17
	3.3 Prohibited Use	18
	3.4 Warning Note Labels	19
	3.4.1 Notes placed on the product	19
	3.4.2 Adhesive label in the package	19
	3.5 Shock-hazard Protection	19
	3.5.1 Leakage current	19
	3.5.2 Residual current protective device (RCD)	20
	3.5.3 Isolating transformers	20
	3.6 Stop / Emergency Stop / Emergency Off	21
	3.6.1 Stop	21
	3.6.2 Emergency Stop	22
	3.6.3 Emergency Off	22
4	Product Life Cycle Handling	23
	4.1 Transport	24
	4.2 Packaging	24
	4.3 Storage	24
	4.4 Installation, Setup, and Normal operation	25
	4.5 Decommissioning	25
	4.6 Maintenance and Cleaning	25
	4.6.1 Cleaning Procedure	25
	4.7 Disassembly	26
	4.8 System Repair	
	4.8.1 Exchange of the Device	
	4.8.2 Exchange of Other Servo Drive System Parts	
	4.9 Disposal	
5	Package	
	5.1 Package Supplied	
	5.2 Nameplate	
	5.3 Part Number Scheme	
6	Technical Description and Data	
	6.1 The Family of Kollmorgen Essentials Drives	
	6.2 Ambient Conditions, Ventilation and Mounting Position	
	6.3 Mechanical Data	
	6.4 Performance Data	
	6.5 Electrical Data	
	6.5.1 Mains supply data, 1 phase AC	
	6.5.2 Mains supply data, 3 phase AC	
	6.5.3 Output data	
	6.5.4 Steady State Control Current per Brake Option	
	6.6 Electrical Motor Braking	
	6.6.1 Drive dynamic braking	38

	6.6.2 Regenerative braking	38
	6.6.2.1 Functional description	38
	6.6.2.2 Technical data - 240V servo drives	39
	6.7 LED and Push-button B1	40
7	Mechanical Installation	42
	7.1 Important Notes	43
	7.2 Guide to Mechanical Installation	43
	7.3 Dimensions	44
8	Electrical Installation	45
	8.1 Important Notes	46
	8.2 Guide to Electrical Installation	47
	8.3 Wiring	48
	8.3.1 General	48
	8.3.2 Mating connectors	48
	8.3.3 Cable and Wire Requirements	49
	8.3.3.1 Cable cross sections and requirements	49
	8.3.3.2 Kollmorgen Essentials Hybrid Cable Wiring Specifications	49
	8.3.4 Protective Earth Connection	50
	8.4 EMI Noise Reduction	51
	8.4.1 Reducing EMI noise	51
	8.4.2 Shielding with External Shielding Busbar	52
	8.4.2.1 Shielding Concept	52
	8.4.2.2 Shielding Busbar	53
	8.4.3 Shielding Connection to the Servo Drive	54
	8.4.3.1 Shielding Concept	54
	8.4.3.2 Grounding Shield Connection Clamp	55
	8.5 Connection Overview	56
	8.5.1 Connector Position - Kollmorgen Essentials Drive 6V0312	56
	8.5.2 Wiring Overview	57
	8.5.2.1 KED-SPM-6V03 and KED-SPM-6V06 Connection Diagram	57
	8.5.2.2 KED-SPM-6V12 Connection Diagram	58
	8.5.3 Connector Pinout	59
	8.5.3.1 X1: Motor power and brake	59
	8.5.3.2 X3: Mains, regen resistor, DC-Bus	60
	8.5.3.3 X10: 24 VDC and STO input	61
	8.5.3.4 X11/12: Industrial Ethernet	62
	8.5.3.5 X20: Service	62
	8.5.3.6 X21: I/O	63
	8.5.3.7 X23: Single-cable Feedback	63
	8.6 Power and Logic Voltage Supply (X3/X10)	64
	8.6.1 Electrical Supply Connection	64
	8.6.1.1 Connection to various mains supply networks - 240V servo drive	
	6.0.1.1 Connection to various mains supply networks - 2407 servo drive	
	8.6.2 Mains Power Supply Connector X3	64
		64 65
	8.6.2 Mains Power Supply Connector X3	64 65
	8.6.2 Mains Power Supply Connector X3 8.6.2.1 Wiring examples mains power supply	64 65 66
	8.6.2 Mains Power Supply Connector X3 8.6.2.1 Wiring examples mains power supply 8.6.2.2 Fusing	64 65 66 68
	8.6.2 Mains Power Supply Connector X3 8.6.2.1 Wiring examples mains power supply 8.6.2.2 Fusing 8.6.3 Auxiliary Voltage Power Supply Connector X10	64 65 66 68 69
	8.6.2 Mains Power Supply Connector X3 8.6.2.1 Wiring examples mains power supply 8.6.2.2 Fusing 8.6.3 Auxiliary Voltage Power Supply Connector X10 8.6.3.1 Fusing	64 65 68 69 69
	8.6.2 Mains Power Supply Connector X3 8.6.2.1 Wiring examples mains power supply 8.6.2.2 Fusing 8.6.3 Auxiliary Voltage Power Supply Connector X10 8.6.3.1 Fusing 8.6.3.2 Wiring example 24 VDC supply	64 65 66 69 69 70
	8.6.2 Mains Power Supply Connector X3 8.6.2.1 Wiring examples mains power supply 8.6.2.2 Fusing 8.6.3 Auxiliary Voltage Power Supply Connector X10 8.6.3.1 Fusing 8.6.3.2 Wiring example 24 VDC supply	64 65 68 69 69 70
	8.6.2 Mains Power Supply Connector X3 8.6.2.1 Wiring examples mains power supply 8.6.2.2 Fusing 8.6.3 Auxiliary Voltage Power Supply Connector X10 8.6.3.1 Fusing 8.6.3.2 Wiring example 24 VDC supply 8.7 DC Bus Link Connector X3 8.7.1 DC Bus sharing between Kollmorgen Essentials Drives	64 65 68 69 69 70 71
	8.6.2 Mains Power Supply Connector X3 8.6.2.1 Wiring examples mains power supply 8.6.2.2 Fusing 8.6.3 Auxiliary Voltage Power Supply Connector X10 8.6.3.1 Fusing 8.6.3.2 Wiring example 24 VDC supply 8.7 DC Bus Link Connector X3 8.7.1 DC Bus sharing between Kollmorgen Essentials Drives 8.8 Regen Resistor Connector X3	64 65 66 69 69 70 71 72
	8.6.2 Mains Power Supply Connector X3 8.6.2.1 Wiring examples mains power supply 8.6.2.2 Fusing 8.6.3 Auxiliary Voltage Power Supply Connector X10 8.6.3.1 Fusing 8.6.3.2 Wiring example 24 VDC supply 8.7 DC Bus Link Connector X3 8.7.1 DC Bus sharing between Kollmorgen Essentials Drives 8.8 Regen Resistor Connector X3 8.9 Motor Power, Brake, and Feedback Connection	64 65 68 69 69 70 72 73

	8.9.2.1 Motor power and brake connector X1	74
	8.9.2.2 Motor leads to servo drive connector X1	74
	8.9.2.3 Motor feedback cable connector to servo drive feedback connector X23	75
	8.9.3 Motor Holding Brake Connection	
	8.9.4 Feedback Connector X21	
	8.9.4.1 X21 Feedback Connector Pinout	78
	8.9.5 Feedback Connector X23	
	8.10 Industrial Ethernet Interface Connector X11/X12	
	8.10.1 EtherCAT®	
	8.10.2 PROFINET	
	8.10.3 EtherNet/IP	
	8.11 Service Interface Connector X20	
	8.11.1 Cables	
	8.11.2 Ferrites	
	8.12 Digital I/O - X21	
_	8.12.1 X21 Connector Pinout	
9	Setup	
	9.1 Important Notes	
	9.2 Guide to Servo Drive Setup	
	9.2.1 Initial Procedure for Servo Drive Test	
	9.2.1.1 Unpacking, mounting, and wiring the Kollmorgen Essentials Drive	
	9.2.1.2 Minimum wiring for servo drive test without load, example	
	9.2.1.3 Confirm connections (example: directly to PC)	
	9.2.1.4 Industrial Ethernet Setup	
	9.2.1.5 Install and start WorkBench	
	9.2.1.6 Setup the axis in WorkBench	
	9.2.1.7 Enable the axis (Hardware)	
	9.2.1.8 Move the motor axis	
	9.2.1.9 Tune the axis	
	9.2.2 WorkBench Installation	
	9.2.2.1 Use as directed	
	9.2.2.2 Software description	
	9.2.2.3 Hardware requirements	
	9.2.2.4 Operating systems	
	9.2.2.5 Installation under Windows 7/8/10/11	
	9.3 Switch-On and Switch-Off Behavior	
	9.3.1 Switch-on Behavior in Standard Operation	
	9.3.2 Switch-off Behavior	
	9.3.2.1 Switch-off behavior using the AXIS#.DIS command 9.3.2.2 Switch-off behavior using a digital input (controlled stop)	
	9.3.2.3 Switch-off behavior using STO input (uncontrolled stop)	
	9.3.2.4 Switch-off behavior in the event of a fault	
	9.4 Fault and Warning Messages	
	9.5 Troubleshooting	
4) Safety Manual for FS1	
	10.1 General Notes	
	10.1.1 Use as directed	
	10.1.2 Prohibited use	
	10.1.3 Abbreviations used for functional safety	
	10.1.4 Enclosure, wiring	
	10.2 Verification	
	10.3 Safety Function Option 1 (I/O, SIL2 PLd)	
	10.3.1 Safety Properties Overview	
	10.3.2 Technical Data	
	10.0.2 Toolinida Data	112

10.3.3 STO (Safe Torque Off)	114
10.3.3.1 Important Notes	
10.3.3.2 Activation	
10.3.3.3 Restart	
10.3.3.4 Timing	
10.3.3.5 Safety Diagnostic view in WorkBench	116
10.3.3.6 Fault Reaction / Failure Messages	117
10.4 Safety Faults, Safety Warnings	
10.4.1 Drive Safety Faults	118
10.4.2 Safety Warnings	
10.4.3 Troubleshooting Functional Safety	119
10.5 Functional Safety Parameter Reference	120
10.5.1 Safety Parameters, sorted alphanumeric	121
10.5.1.1 AXIS#.SAFE.STO.A	121
10.5.1.2 AXIS#.SAFE.STO.B	122
10.5.1.3 AXIS#.SAFE.STO.ACTIVE	123
10.5.1.4 AXIS#.SAFE.STO.REPORTFAULT	124
11 Essentials Cables	125
11.1 Essentials Cable Properties	125
11.2 Essentials Cable Nomenclature	126
11.3 Essentials Cable Connector Pinouts	127
12 Accessories for Kollmorgen Essentials Drives	128
13 Certificates and Declarations	129
13.1 Conformance with UL/cUL & CSA	130
13.1.1 3-12 A drives	130
13.2 Conformance with EU	132
13.2.1 Conformance with RoHS	132
13.2.2 Conformance with REACH	
13.3 Conformance with PFAS	132
13.4 Conformance with CAL_Prop65	133
13.5 Conformance with POP	133
13.6 Conformance with TSCA	133
13.7 Conformance with EtherCAT	133
14 Index	134
15 Record of Document Revisions	136
16 Copyrights, Trademarks, Patents, and Disclaimers	137
Support and Services	139

1 Welcome to Kollmorgen Essentials



The Kollmorgen Essentials System is a mid-featured motion control system consisting of servo motors, servo drives, and cables. The system is designed to be scalable from plug-and-play to highly customized tuning in WorkBench. Simply hook a Kollmorgen Essentials Drive up to a Kollmorgen Essentials Motor using a Kollmorgen Essentials Cable on your network, and open WorkBench. WorkBench can walk you through a few steps to set up the drive.

Kollmorgen Essentials Drive Models

Current Rating	Medium Voltage (6V)
ЗА	KED-SPM-6V03S
6A	KED-SPM-6V06S
12A	KED-SPM-6V12S

Kollmorgen Essentials Motor Models

Power Rating	120 / 240V _{AC} 1Ø - 3Ø	240 / 480V _{AC} 3Ø
200W	KEM-2V020	
400W	KEM-2V040	KEM-4V040
750W	KEM-2V075	KEM-4V075
1000W	KEM-2V100	KEM-4V100
1500W	KEM-2V150	KEM-4V150
2500W	KEM-2V250	KEM-4V250
3000W	KEM-2V300	KEM-4V300
4000W		KEM-4V400

- See Compare Kollmorgen Essentials Drives to AKD2G and AKD Drives.
- See Essentials Drive Installation about setting up the Kollmorgen Essentials Drive.
- See Essentials Motor Installation about setting up the Kollmorgen Essentials Motor.

2 General

2.1	About this Installation Manual	9
2.2	Symbols Used	10
	Abbreviations Used	

2.1 About this Installation Manual

This Installation Manual describes the Kollmorgen Essentials Drive series of digital servo drives and includes information to safely install the product.

Manual updates can be downloaded from the Kollmorgen website (www.kollmorgen.com).

Product information for use consists of:

- Product Support Page: http://www.kollmorgen.com/kes/
- · Safety Notes: Multilingual document with safety information
- *Installation Manual*: Describes the product series of digital drives and includes information to safely install it. Contact Kollmorgen customer support for a printed copy of the installation manual.
- Essentials Documentation Portal: webhelpdev.kollmorgen.com/essentials/english/, contains a superset of all Essentials documentation
- EtherCAT® Communication: Describes how to use your drive in EtherCAT applications.
- *EtherNet/IP™ Communication*: Describes how to use your drive in EtherNet/IP applications.
- PROFINET® Communication: Describes how to use your drive in PROFINET applications.
- Accessories Manual: Provides information for accessories like cables and regen resistors used with your product. Regional variants of this manual available.

2.2 Symbols Used

2.2.1 Warning Symbols

Symbol	Indication
A DANGER	Indicates a hazardous situation which, if not avoided, will result in death or serious injury.
<u>^</u>WARNING	Indicates a hazardous situation which, if not avoided, could result in death or serious injury.
⚠ CAUTION	Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
NOTICE	Indicates situations which, if not avoided, could result in property damage.
NOTE	This symbol indicates important notes.
	High Noise Pollution. The type of danger is specified by the text next to the symbol.
	Warning of a danger (general). The type of danger is specified by the text next to the symbol.
4	Warning of danger from electricity and its effects.
<u></u>	Warning of danger from hot surface.
	Warning of danger from suspended loads.
	Warning of danger from automatic start.
	Warning of danger from molten particle projection.

2.2.2 Drawing Symbols

Symbol	Description	Symbol	Description
	Signal ground	*	Diode
n.m.	Chassis ground / EMC-grounded	+	Relay
	Protective earth	■	Relay switch off delayed
ф	Resistor	\'	Normally open contact
ф	Fuse	7	Normally closed contact
Device	State-of-the-art firewall		EMC filter

2.3 Abbreviations Used

Abbreviations related to functional safety (\rightarrow # 108).

Abbreviation	Meaning
(→ # 53)	"see page 53" in this document
→ xyz	"see chapter xyz" in this document
Ω	Ohms
A#, AXIS#	A# or AXIS# are used for axis 1, with parameters or signal names.
AGND	Analog ground
AquadB	In quadrature output, used for incremental encoder emulation
AMSL	Above mean sea level
Axis	Depends on context, either one servo servo drive output stage or one load axis of the full motion system.
CAT	Category
CE	Communité Européenne
СОМ	Serial interface for a personal computer
DGND	Digital ground
EEPROM	Electrically erasable programmable memory
EEO	Emulated Encoder Output
EMC	Electromagnetic compatibility
EMF	Electromagnetic force
FS1	Functional Safety Option 1
FSoE	Fail safe over EtherCAT
KAS	Kollmorgen Automation Suite
KAS IDE	Setup software (Kollmorgen Automation Suite Integrated Development Environment)
KDN	Kollmorgen Developer Network
LED	Light-emitting diode
LSB	Low significant byte (or bit)
MSB	Most significant byte (or bit)
NI	Zero pulse
OSSD	Output Signal Switching Device

PE	Protective earth
PELV	Protective Extra Low Voltage
PLC	Programmable logic control
PWM	Pulse-width modulation
RAM	Random access memory (volatile memory)
RBrake/RB	Regen resistor (also called a brake resistor)
RBext	External regen resistor
RCD	Residual current device
RES	Resolver
S1	Continuous operation
tbd	To be determined (in progress)
VAC	Volts, alternating current
VDC	Volts, direct current

3 Product Safety

To avoid possible damage, read and follow the instructions.

3 1	You should pay attention to this	15
	Use as Directed	
3.3	Prohibited Use	. 18
	Warning Note Labels	
	Shock-hazard Protection	
3.6	Stop / Emergency Stop / Emergency Off	.21

3.1 You should pay attention to this

This section helps to recognize risks and avoid dangers to people and objects.

Specialist staff required!

The devices are intended for industrial applications.

Machine builders must employ qualified personnel. Qualified personnel are people who have been trained to transport, install, commission, and operate electrical drives.

- Transport, storage, unpacking: Only by personnel with knowledge of handling electrostatically sensitive components.
- · Mechanical installation: Only by personnel with mechanical expertise.
- · Electrical installation: Only by personnel with expertise in electrical engineering.
- Basic tests / setup: Only by personnel with expertise in electrical engineering and drive technology.

The qualified personnel must know and observe ISO 12100 / IEC 60364 / IEC 60664 and national accident prevention regulations.

Read the documentation!

Read the available documentation before installation and commissioning. Improper handling of the devices can cause harm to people or damage to property. The operator of systems using the drive system must ensure that all personnel who work with the drive read and understand the manual before using the drive.

Check Hardware Revision!

Check the Hardware Revision Number of the product (see product label). This number is the link between your product and the manual. The product Hardware Revision Number must match the Hardware Revision Number on the cover page of the manual.

Pay attention to the technical data!

Adhere to the technical data and the specifications on connection conditions. If permissible voltage values or current values are exceeded, the devices can be damaged. Unsuitable motor or wrong wiring will damage the system components. Check the combination of drive and motor. Compare the rated voltage and current of the units.

Perform a risk assessment!

The manufacturer of the machine must generate a risk assessment for the machine, and take appropriate measures to ensure that unforeseen movements cannot cause injury or damage to any person or property. Additional requirements on specialist staff may also result from the risk assessment.

Automatic restart!



Risk of death or serious injury for humans working in the machine. The servo drive might restart automatically after power on, voltage dip or interruption of the supply voltage, depending on the parameter setting.

If the parameter AXIS#.ENDEFAULT is set to 1, then place a warning sign on the machine (Warning: Automatic Restart at Power On) and ensure, that power on is disabled, while humans are in a dangerous zone of the machine. In case of using an undervoltage protection device, you must observe EN 60204-1:2006 chapter 7.5.

ATTENTION: The servo drive can be ready to operate when 24V are applied to STO inputs.

Observe electrostatically sensitive components!

The devices contain electrostatically sensitive components which may be damaged by incorrect handling. Electrostatically discharge your body before touching the device. Avoid contact with highly insulating materials (artificial fabrics, plastic film etc.). Place the device on a conductive surface.

Hot surface!



Risk of minor burns! Drives may have hot surfaces during operation. The housing can reach temperatures above 80 °C. Measure the temperature and wait until the housing has cooled down below 40 °C before touching it.

Earthing!



Risk of electric shock! Ensure that the drive is safely earthed to the PE (protective earth) busbar in the switch cabinet. Without low-resistance earthing personal protection is at risk.

Leakage Current!

Since the leakage current to PE is more than 3.5 mA, double the PE connection or use a connecting cable with a cross-section >10 mm² to be compliant with IEC 61800-5-1.

Deviating measures according to regional standards might be possible.

High voltages!





The equipment produces high electric voltages up to 500V. Lethal danger exists at live parts of the device. Do not open or touch the equipment during operation. Keep all covers and cabinet doors closed. Built-in protection measures such as insulation or shielding may not be removed. Work on the electrical installation may only be performed by trained and qualified personnel, in compliance with the regulations for safety at work, and only with switched off mains supply, and secured against restart.

Never undo any electrical connections to the servo drive while it is live. There is a danger of electrical arcing with damage to contacts and personal injury. Wait at least 5 minutes after disconnecting the servo drive from the main supply power before touching potentially live sections of the equipment (such as contacts) or removing any connections.

Always measure the voltage in the DC bus link and wait until the voltage is below 50 V before handling components.

Ejection of molten particles!



If particles fall into the drive or the drive has been damaged, molten drive component particles may be ejected causing injuries. Shut down the drive and wear appropriate protective gear during maintenance work, troubleshooting and fault rectification. (System Repair, → # 26)

Functional Safety!

You are responsible for the assessment of the safety functions according to EN 13849 or EN 62061.

Reinforced Insulation

Thermal sensors, motor holding brakes and feedback systems built into the connected motor must have reinforced insulation (according to IEC 61800-5-1) against system components with power voltage, according to the required application test voltage. All Kollmorgen components meet these requirements.

Never modify the drive!



Never open the cover of the drive, as the electronic components installed there generate dangerous high voltages. Even after disconnection from the mains, the components often still carry high voltage.

Therefore, the drive may only be opened by authorized specialist personnel.

Kollmorgen shall not be held accountable for any defects, malfunctions or degradations resulting from users opening up the device. In case of damage or malfunction, send the drive for repair or replacement.

3.2 Use as Directed

Use your Kollmorgen Essentials Drive exclusively with Kollmorgen Essentials Motors and Kollmorgen Essentials Cables, or with suitable synchronous servo motors, such as Kollmorgen AKM, AKMH and AKM2G with SFD-M or SFD3 feedback, that are capable of closed-loop control of torque, speed, and/or position.

Your servo drive is a component that is built into electrical plants or machines and can only be operated as integral component of these plants or machines. The manufacturer of the machine used with a servo drive must conduct a risk assessment for the machine. When the servo drive is built into a machine or plant, it must not be used until it has been established that the machine or plant fulfills the requirements of the regional rules, laws and regulations.

Cabinet and wiring

Only operate your device in a closed control cabinet suitable for the ambient conditions (\rightarrow # 35). Make sure to keep the temperature within the cabinet within the acceptable limits with help of ventilation or cooling.

Only use copper conductors for wiring. The conductor cross-sections can be derived from the standard IEC 60204-1 for CE, and NEC Table 310-16, 75C column for USA, or equivalent codes for other nationalities, including applicable deratings.



If you cannot operate your servo drive in a control cabinet, contact Kollmorgen. Additional protective equipment (e.g. for connector X1) may be required, depending on the servo drive model and use case.

Power supply

The servo drives can be supplied by 1, 2 or 3 phase (TN-S or TT).

Servo drives in the Kollmorgen Essentials Drive series can be supplied as follows:

KED-SPM-6V:

1, 2 or 3 phase industrial supply networks: 100V_{AC} or 240V_{AC} nominal.

Connection to other voltage types of supply networks is possible with an additional isolating transformer.

Periodic overvoltage's between phases (L1, L2, L3) and the PE/housing of the drive must not exceed 1000V peak. In accordance with IEC 61800:

- Voltage spikes (< 50 μs) between phases must not exceed 1000V.
- Voltage spikes (< 50 μs) between a phase and the PE/housing must not exceed 2000V.

Motor voltage rating

The rated voltage of the motors must be at least as high as the DC bus link voltage divided by $\sqrt{2}$ produced by the servo drive $(U_{nMotor}>=U_{DC}/\sqrt{2})$.

Functional Safety



- The network, to which the servo drive is connected, must be secured according to state-ofthe-art information technology security requirements.
- The user IT specialists shall analyze whether further security requirements are applicable to ensure functional safety.

Read chapter "Use as Directed" in the Functional Safety section before using safety functionality.

3.3 Prohibited Use

Other use than that described in the previous "Use as Directed" section is not intended and can lead to personnel injuries and equipment damage.

The servo drive may not be used with a machine that does not comply with appropriate

- · national laws,
- rules,
- · regulations and
- · applicable standards.

The use of the servo drive in the following environments is also prohibited:

- · potentially explosive areas
- · environments with corrosive and/or electrically conductive acids, alkaline solutions, oils, vapors, dusts
- · ships or offshore applications



If the network, to which the servo drive is connected, is not secured according to state-of-the-art information technology, this could be a security risk.

3.4 Warning Note Labels

3.4.1 Notes placed on the product

	Attention Before installing or servicing, refer to the installation manual and safety instructions.
5 min.)	Residual Voltage Wait 5 minutes after removing power before servicing.
<u>\(\sqrt{\sq}}}}}}}}}}}}}}}}}}}}}}}}}}}}}}}}}}}}</u>	Hot Surface Do not touch heatsink.
#	Protective Earth Always connect ground wire to terminal with this symbol.
Motor Overload Protection Class 10, 120% FLA Not speed sensitive	Electronic Overload Protection The internal electronic overload protection is not speed sensitive.

3.4.2 Adhesive label in the package



Follow the instructions given on the adhesive labels in the package. If a warning note label is damaged, replace it immediately.

3.5 Shock-hazard Protection

3.5.1 Leakage current

Leakage current via the PE conductor results from the combination of equipment and cable leakage currents. The leakage current frequency pattern includes a number of frequencies, whereby the RCD definitively evaluate the 50/60 Hz current. For this reason, the leakage current cannot be measured using a conventional multimeter. Contact our application department for help to calculate the leakage current in your application.



Since the leakage current to PE is more than 3.5mA, in compliance with IEC 61800-5-1 the PE connection must either be doubled or a connecting cable with a cross-section >10mm² must be used. Use the PE terminal and the PE connection screws in order to fulfill this requirement.

Use the following measures to minimize leakage currents:

- Reduce the length of the motor cable.
- Use low capacitance motor cables (→ #48)

3.5.2 Residual current protective device (RCD)

In conformity with IEC 60364-4-41 - Regulations for installation and IEC 60204-1 - Electrical equipment of machinery, you can use residual current protective devices (RCDs) provided the requisite regulations are complied with.

The servo drive is a 3-phase system with a B6 bridge. Use RCDs which are sensitive to all currents in order to detect any DC fault current.

Rated residual currents in the RCDs:

10 to 30 mA	Protection against "indirect contact" (personal fire protection) for stationary and mobile equipment, as well as for "direct contact".
30 to 50 mA	Protection against "indirect contact" (personal fire protection) for stationary equipment

Recommendation:

Protect each servo drive individually using a 30mA RCD which is sensitive to all currents to secure against direct contact (with motor cables shorter than 5m).

If you use a selective RCD, the more intelligent evaluation process will prevent spurious tripping of the RCD.

3.5.3 Isolating transformers

When protection against indirect contact is absolutely essential despite a higher leakage current, or when an alternative form of shock-hazard protection is sought, the servo drive can also be operated by using an isolating transformer. Use a ground-leakage monitor to detect short circuits.

Note: Keep the length of wiring between the transformer and the servo drive as short as possible.

3.6 Stop / Emergency Stop / Emergency Off

The control functions Stop, Emergency Stop, and Emergency Off are defined by IEC 60204-1.

Notes for functional safety aspects of these functions can be found in ISO 13849 and IEC 62061.

NOTE

The parameter AXIS#.DISMODE must be set to implement the different stop categories for software disabling. Consult the WorkBench Online Help for configuring the parameter. Only STO (stop category 0) is a certified safety function.



WARNING Vertical load could fall!

Serious injury could result when the load is not properly blocked. The internal brake function does not ensure functional safety.

- Functional safety, e. g. with hanging loads (vertical axis) requires one or more safe brakes, depending on required safety level. These brakes must be controlled by an external safe brake controller.
- · The STO and Hardware Enable (if configured) do not initiate a controlled stop but switches off the power stage immediately.
- Set parameter AXIS#.MOTOR.BRAKEIMM to 1 with vertical axes, to apply the brake immediately after faults or Hardware Disable.
- Risk assessment of the application determines the necessary measures.

3.6.1 Stop

The stop function shuts down the machine in normal operation and is defined by IEC 60204.

NOTE

The Stop Category must be determined by a risk evaluation of the machine.

Stop function must have priority over assigned start functions. The following stop categories are defined:

Stop Category 0

Shut-down by immediate switching-off the energy supply to the servo drive machinery (this is an uncontrolled shutdown).

For stop without using safety functions like STO, set AXIS#.DISMODE to 0.

The safety function STO stops the servo drive as required by Stop Category 0 (IEC 62061).

Stop Category 1

A controlled shut-down, whereby the energy supply to the servo drive machinery is maintained to perform the shutdown, and the energy supply is only interrupted when the shut-down has been completed.

To achieve this behavior, set AXIS#.DISMODE to 2.

Stop Category 2

A controlled shut-down, whereby the energy supply to the servo drive machinery is maintained.

Stop Category 0 and Stop Category 1 stops must be operable independently of the operating mode, whereby a Category 0 stop must have priority. Hardwired STO has always the highest priority.

If necessary, provision must be made for the connection of protective devices and lock-outs. A reset of the stop function must not create a hazardous situation.

3.6.2 Emergency Stop

The Emergency Stop function is used for the fastest possible shutdown of the machine in a dangerous situation. The Emergency Stop function is defined by IEC 60204. Principles of emergency stop devices and functional aspects are defined in ISO 13850.

The Emergency Stop function will be triggered by the manual actions of a single person. It must be fully functional and available at all times. The user must understand instantly how to operate this mechanism (without consulting references or instructions).

NOTE The S

The Stop Category for the Emergency Stop must be determined by a risk evaluation of the machine.

In addition to the requirements for stop, the Emergency Stop must fulfill the following requirements:

- Emergency Stop must have priority over all other functions and controls in all operating modes.
- The energy supply to any servo drive machinery that could cause dangerous situations must be switched off as fast as possible, without causing any further hazards (Stop Category 0) or must be controlled in such a way, that any movement that causes danger, is stopped as fast as possible (Stop Category 1).
- The reset must not initiate a restart.

3.6.3 Emergency Off

The Emergency Off function is used to switch-off the electrical power supply of the machine. This is done to prevent users from any risk from electrical energy (for example electrical impact). Functional aspects for Emergency Off are defined in IEC 60364-5-53.

The Emergency Off function will be triggered by the manual actions of a single person.

NOTE

The result of a risk evaluation of the machine determines the necessity for an Emergency Off function.

Emergency Off is done by switching off the supply energy by electro-mechanical switching devices. This results in a category 0 stop. If this stop category is not possible in the application, then the Emergency Off function must be replaced by other measures (e.g., by protection against direct touching).

4 Product Life Cycle Handling

4.1	Transport	24
	Packaging	
	Storage	
4.4	Installation, Setup, and Normal operation	25
	Decommissioning	
4.6	Maintenance and Cleaning	25
4.7	Disassembly	26
4.8	System Repair	26
4.9	Disposal	27

4.1 Transport

Transport the Kollmorgen Essentials Drive in accordance with IEC 61800-2 as follows:

- Transport only by qualified personnel in the manufacturer's original recyclable packaging.
- · NOTICE: Avoid shocks while transporting.
- Vibration/Shock: Kollmorgen Essentials Drive is tested for environmental class 2M1 of IEC 60721-3-2.
- Store at or below a maximum stacking height of 8 cartons. (Storage, → #24)
- Transport only within specified temperature ranges:
 -25 to +70 °C, max. rate of change 20 K/hour, class 2K3.
- Transport only within specified humidity: max. 95% relative humidity at +40°C, no condensation, class 2K3.

NOTICE

The servo drives contain electrostatically sensitive components that can be damaged by incorrect handling. Electrostatically discharge yourself before touching the servo drive. Avoid contact with highly insulating materials, such as artificial fabrics and plastic films. Place the servo drive on a conductive surface.

If the packaging is damaged, check the unit for visible damage. Inform the shipper and the manufacturer of any damage to the package or product.

4.2 Packaging

The Kollmorgen Essentials Drive packaging consists of recyclable cardboard with inserts and a label on the outside of the box.

Model	Package (mm) HxWxL	Total Weight (kg)	
KED-6V03/KED-6V06	108 x 295 x 295	1.7	
KED-6V12	108 x 295 x 295	2.4	

NOTE

Mating connectors

- X1 (Motor Power) and X23 (Feedback Connector) are provided on the hybrid motor cable (sold separately). See also "Cables" chapter in Kollmorgen Essentials Drive Installation Manual.
- X10 (Auxiliary Voltage Power Supply Connector) and X3 (Mains Power Connector) are included.
- X11/12 (Industrial Ethernet Interface Connectors) are standard Industrial Ethernet connections. Cables need to be provided by the user.
- X20 (Service Interface Connector) is a standard USB-C connection. Cables need to be provided by the user.
- X21 (Digital I/O) is based on standard D-Sub connections. Cables need to be provided by the user.

Other connectors and cables need to be provided by the user.

4.3 Storage

Store the Kollmorgen Essentials Drive in accordance with EN 61800-2 as follows:

- · Store only in the manufacturer's original recyclable packaging.
- Store at or below a maximum stacking height of 8 cartons.
- Store only within the specified temperature ranges:
 - -25 to +55 °C, max. rate of change 20 K/hour, class 1K4.

- Store only within the specified humidity:
 - 5 to 95% relative humidity, no condensation, class 1K3.
- Store in accordance with the following duration requirements:
 - · Less than 1 year: without restriction.
 - · More than 1 year: capacitors must be re-formed before setting up and operating the servo drive.
- A rubber plug is provided with the servo drive. Use it for the USB-C slot for protection against particle ingress.

4.4 Installation, Setup, and Normal operation

- Mechanical installation (→ # 42)
- Electrical installation (→ # 45)
- Setup (→ #87)

Normal operation tested for environmental class 3K3 according to EN 61800-2 (→ # 35).

The manufacturer of the machine defines the necessary end user expertise based on the risk assessment for the machine and describes the requirements for normal operation based on the application.

4.5 Decommissioning



Only professional staff who are qualified in electrical engineering are allowed to decommission parts of the system.

Danger: Lethal Voltages!

There is a danger of serious personal injury or death by electrical shock or electrical arcing.

- 1. Switch off the main switch of the switchgear cabinet.
- 2. Secure the system against restarting.
- 3. Block the main switch.
- 4. Wait at least 5 minutes after disconnecting.

4.6 Maintenance and Cleaning

The device does not require maintenance, it should be inspected once a year by professional staff.



Do not immerse or spray the device.

Avoid that liquid enters the device.

The inside of the unit can only be cleaned by the manufacturer.

Opening the device voids the warranty.

4.6.1 Cleaning Procedure

1. Decommission the device.

See (Decommissioning, \rightarrow # 25).

2. Casing: Clean with Isopropanol or similar cleaning solution.

Caution: Highly Flammable! Risk of injury by explosion and fire.

- Observe the safety notes given on the cleaning liquid package.
- Wait at least 30 minutes after cleaning before putting the device back into operation.
- 3. Protective grill on fan: Clean with a dry brush.

4.7 Disassembly

NOTICE

Only professional staff who are qualified in electrical engineering are allowed to disassemble parts of the system.

1. Decommission the device.

See (Decommissioning, → #25).

2. Check temperature.

Caution: High Temperature! Risk of minor burns.

During operation, the heat sink of the drive may reach temperatures above 80 °C (176 °F).

Before touching the device, check the temperature and wait until it has cooled below 40 °C (104 °F).

3. Remove the connectors.

Disconnect the potential earth connection last.

4. Demount: Loosen the fastening screws.

Remove the device.

4.8 System Repair



Only professional staff who are qualified in electrical engineering are allowed to exchange parts of the drive system.

Caution: Automatic Restart! During replacement work a combination of hazards and multiple episodes may occur.

Work on the electrical installation may only be performed by trained and qualified personnel, in compliance
with the regulations for safety at work, and only with use of prescribed personal safety equipment.

4.8.1 Exchange of the Device

Only the manufacturer can repair the device.

Opening the device or housing voids the warranty.

1. Decommission the device.

See (Decommissioning, \rightarrow # 25).

2. Demount the device.

See (Disassembly, \rightarrow # 26).

3. Send the device to the manufacturer.

See (Disposal, \rightarrow # 27).

- 4. Install a new device as described in the Installation Manual.
- 5. Setup the system as described in the Installation Manual.

4.8.2 Exchange of Other Servo Drive System Parts

Use this procedure if parts of the servo drive system (e.g., cables) must be replaced.

1. Decommission the device.

See (Decommissioning, \rightarrow # 25).

- 2. Exchange the parts.
- 3. Check all connections for correct fastening.
- 4. Setup the system as described in the Installation Manual.

4.9 Disposal



• To dispose the unit properly, contact a certified electronic scrap disposal merchant.

In accordance with the WEEE-2012/19/EU guideline and similar, the manufacturer accepts returns of old devices and accessories for professional disposal. The sender needs to cover the costs for the transport.

Contact Kollmorgen to clarify the logistics.

Send the device in the original packaging to the manufacturer address:

North America	South America
KOLLMORGEN	Altra Industrial Motion do Brasil
201 West Rock Road	Equipamentos Industriais LTDA.
Radford, VA 24141, USA	Avenida João Paulo Ablas, 2970
	Jardim da Glória, Cotia – SP
	CEP 06711-250, Brazil
Europe	Asia
KOLLMORGEN s.r.o	KOLLMORGEN
Evropská 864664 42 Modřice, Brno	Room 302, Building 5, Lihpao Plaza,
Czech Republic	88 Shenbin Road, Minhang District,
	Shanghai, China.

5 Package

5.1	Package Supplied	29
	Nameplate	
5.3	Part Number Scheme	31

5.1 Package Supplied

The package includes:

- Kollmorgen Essentials Drive
- · Quick Start Guide
- · Panel safety label

NOTE

Mating connectors

- X1 (Motor Power) and X23 (Feedback Connector) are provided on the hybrid motor cable (sold separately). See also "Cables" chapter in Kollmorgen Essentials Drive Installation Manual.
- X10 (Auxiliary Voltage Power Supply Connector) and X3 (Mains Power Connector) are included.
- X11/12 (Industrial Ethernet Interface Connectors) are standard Industrial Ethernet connections. Cables need to be provided by the user.
- X20 (Service Interface Connector) is a standard USB-C connection. Cables need to be provided by the user.
- X21 (Digital I/O) is based on standard D-Sub connections. Cables need to be provided by the user.

Other connectors and cables need to be provided by the user.

Accessories sold separately

Please order accessories separately if required, see (Accessories for Kollmorgen Essentials Drives, → # 128).

- EMC filters for mains supply voltage, categories C2 or C3
- · External regen resistor
- · Mating connector kits
- Motor chokes
- · Hybrid motor cables with connectors

5.2 Nameplate

A nameplate is attached to the side of the servo drive. Example:

KOLLMORGEN

Customer Support: North America: +1 (540) 633-3400 Europe: +49 (0) 2102-9394-0 Italy: +39 (0) 362-594260

201 W. Rock Road Radford, VA 24141

Model No: KED-SPM-6V03S-A100-0000

Serial No: B2-2252-10039 HW Rev: AA

Ratings at 40°C (See manual for ratings >40°C)

 INPUT
 OUTPUT

 Voltage
 120-240 VAC
 0-240 Vac

 Frequency
 50/60 Hz
 0-599Hz

 Phase
 1 Ph/3 Ph
 3 Ph

 FL Current
 4/3.2 Arms
 3 Arms

Power @ 240 Vac 0.9/1.3 kVA

Enclosure Protection Rating: IP20



www.kollmorgen.com








Assembled in Czech republic - BCZ

5.3 Part Number Scheme

Use the part number scheme for product identification only.



Kollmorgen Essentials Drive Options 120/240 VAC, 1φ/3φ

- KED-SPM-6V03S-A100-0000-A
- KED-SPM-6V06S-A100-0000-A
- KED-SPM-6V12S-A100-0000-A

Kollmorgen Essentials Drive Options 240/480 VAC, 3φ

- KED-SPM-7V03S-A100-0000-A
- KED-SPM-7V06S-A100-0000-A
- KED-SPM-7V12S-A100-0000-A

6 Technical Description and Data

6.1	The Family of Kollmorgen Essentials Drives	33
6.2	Ambient Conditions, Ventilation and Mounting Position	35
	Mechanical Data	
6.4	Performance Data	36
6.5	Electrical Data	36
6.6	Electrical Motor Braking	38
6.7	LED and Push-button B1	40

6.1 The Family of Kollmorgen Essentials Drives

Available Kollmorgen Essentials Drive versions

Connectivity	Rated Voltages	Current	Axis	Rev	Funct. Safety
M : Multi-Ethernet (EtherNet/IP, EtherCAT, PROFINET)	6V : 120/240VAC 1~ 240VAC 3~	03 : 3A 06 : 6A 12 : 12A	S : Single Axis	A	1:SIL2 STO

Standard features

- · Support for secondary incremental position input
- 2 high-speed and 2 regular speed digital inputs, 2 digital outputs
- · Single axis
- · Supply voltages:
 - · AC single phase, split phase, three phase AC neutral
 - Single or group supply, single or group mains fusing
- · Industrial Ethernet on board
- SFD-M, SFD3
- · Step/Direction input
- Use with AC synchronous servomotors and open loop induction machines

Power section

- Single or three phase AC supply, 5% to 110% of rated AC voltage over 47 to 63 Hz. Connection to higher AC voltage mains only by using isolating transformer.
- Three phase bridge rectifier, integral soft-start circuit.
- DC bus link voltage can be connected in parallel for power sharing.
- · Floating current sensors measure actual motor current
- Regenerative circuit with dynamic distribution of the generated power between several servo drives on the same DC bus link circuit.
- · External regen resistor required

Functional Safety Option

• FS1: STO; SIL2 PLd, command by I/O (→ # 112)

Electrical safety

- Appropriate insulation / creepage distances and electrical isolation for safe electrical separation, per IEC 61800-5-1, between the power input / motor connections and the signal electronics.
- Soft-start, over voltage detection, short-circuit protection, phase-loss detection.
- Temperature monitoring of the servo drive and motor.
- Electronic Class 10 motor overload protection: foldback mechanism or optional fault response. The internal electronic overload protection is not speed sensitive.

Auxiliary supply voltage 24 VDC

From an external, safety approved 24V ±10% power supply (PELV).

Parameter setting

- · WorkBench Software for setup via USB
- Download control parameter packages via Industrial Ethernet

Full digital control

- Digital current loop (update 1.28 μs / command 62.5 μs)
- Digital velocity loop (update period 62.5 μs)
- Digital position loop (update period 250 μs)

Inputs/Outputs (X21)

- · 2 high-speed and 2 regular speed digital inputs
- · 2 digital outputs

Connectivity

- Feedback input (→ #79)
- Digital Inputs/Outputs (→ #85)
- Service Interface (→ #84)
- Industrial Ethernet interface (→ # 80)

Accessories

Connector kit with mating connectors X3 and X10

For accessories refer to the (→ Accessories for Kollmorgen Essentials Drives # 128).

6.2 Ambient Conditions, Ventilation and Mounting Position

Storage, Transport	(→ # 24)					
Normal operation	Environmental class 3K3 according to IEC 61800-2					
Surrounding	0 to +40°C under rated					
temperature in operation	• +40°C to +55°C with output current derating 2% per Kelvin					
Humidity in operation	Relative humidity 5 to 85%, no condensation, IEC 61800-2 class 3K3					
Site altitude	Up to 1,000m AMSL (above mean sea level): no restriction					
	• 1,000 to 2,000m AMSL: power derating 1.5%/100m					
	Maximum altitude: 2,000m AMSL					
Pollution level	Pollution level 2 as per IEC 60664-1					
Vibration	Class 3M1 according to IEC 61800-2					
Shock	Class L according to IEC 61800-2					
Servo drive protection	IP 20 according to IEC 60529					
Servo drive EMC immunity	Increased immunity according to EN 61800-5-2					
Mounting	Vertical position, in a cabinet with protection of at least IP 54 Minimum cabinet size (WxHxD): 406 x 406 x 254 mm					
Ventilation	Built-in fan, make sure that the ventilation is not blocked					
NOTICE	The servo drive shuts down in case of excessively high temperature in the control cabinet. Make sure sufficient forced ventilation is supplied within the control cabinet.					

6.3 Mechanical Data

	Unit	6V03	6V06	6V12
Weight	kg	1.1	1.1	2.0
Width	mm	60	60	70
Height, without connectors	mm	172	172	200
Height, with connectors	mm	190	190	225
Depth, without connectors	mm	165	165	202
Depth, with connectors	mm	210	210	255

NOTE Dimension drawing see section Mechanical Installation (→ # 42).

6.4 Performance Data

Performance Data	Units	6V03/ 6V06	6V12
High/Quiet PWM Switching Frequency (optional setting)(dynamic)	kHz	16.0	16.0
Nominal/High Load PWM Switching Frequency (dynamic)	kHz	12.0	12.0
High Load Stalled PWM Switching Frequency (dynamic)	kHz	6.1	6.1
Max. Voltage rise speed dU/dt	kV/μs	7.0	
Current Loop Update Period	μs	1.28	1.28
Velocity Loop Update Period	μs	62.5	62.5
Position Loop Update Period	μs	250	250
Max. Motor Electrical Frequency	Hz	599	

6.5 Electrical Data

6.5.1 Mains supply data, 1 phase AC

Input data	Units	6V03	6V06	6V12
Operational supply voltage (line to line)	VAC	80 to 265		
Rated supply voltage	VAC	100 to 240		
Rated supply input frequency (±5%)	Hz	50 to 60		
Permitted switch on/off frequency	1/h	30		
Rated input VA at 240 V	kVA	1.2	2.3	2.9
Rated input current	А	5.0	9.7	12
Max. inrush current	А	10		
Rated DC bus link voltage	VDC	300		

6.5.2 Mains supply data, 3 phase AC

Input data	Units	6V03	6V06	6V12
Operational supply voltage (Line to Line)	VAC	80 to 265		
Rated supply voltage	VAC	100 to 240		
Rated supply input frequency (±5%)	Hz	50 to 60		
Permitted switch on/off frequency	1/h	30		
Rated input VA at 240 V (* at 480 V)	kVA	0.955	1.9	3.8
Rated input current	А	2.3	4.6	9.2
Max. inrush current	А	10		
Rated DC bus link voltage	VDC	140 to 340		

6.5.3 Output data

	Units	6V03	6V06	6V12			
Continuous output current (± 3%)	Arms	3	6	12			
Peak output current (for 2s, ±3%)	Arms	9	18	30			
Continuous motor shaft output power a	it rated inp	out current	,				
at 1 x 120 VAC	kW	0.22	0.44	0.875			
at 1 x 240 VAC	kW	0.44	0.875	1.8			
at 3 x 120 VAC	kW	0.31	0.625	1.25			
at 3 x 240 VAC	kW	0.625	1.25	2.5			
at 3 x 400 VAC	kW	-	-	-			
at 3 x 480 VAC	kW	-	-	_			
Peak output power (for 1 s)							
at 1 x 120 VAC	kW	1.1	2.1	4.1			
at 1 x 240 VAC	kW	2.1	4.2	6.3			
at 3 x 120 VAC	kW	1.5	3	4.5			
at 3 x 240 VAC	kW	3.0	6.0	9.0			
at 3 x 400 VAC	kW	-	-	-			
at 3 x 480 VAC	kW	-	-	-			
Thermal dissipation, disabled	W	12	12	12			
Thermal dissipation at rated current	W	50	80	140			
Motor inductance							
minimum at 120 VAC	mH	1.2	0.6	0.3			
minimum at 240 VAC	mH	2.4	1.2	0.6			
minimum at 400 VAC	mH	-	-	_			
minimum at 480 VAC	mH	-	-	_			
maximum	mH	240	120	60			
Regeneration Braking	,		(→ # 38)				
Brake output							
Voltage (±10%)	VDC		24				
Output under current fault	mA	mA 100 (required for fault detection)					
Output over current fault	А	2.25 (required for fault detection)					
Output current, maximum	А		2.1				

6.5.4 Steady State Control Current per Brake Option

Auxiliary 24 VDC (±10%, check voltage drop) Supply Voltage (PELV)	Units	Current
Base current with NO brake	Α	< 1
Total current with brake	А	< 2.8

6.6 Electrical Motor Braking

6.6.1 Drive dynamic braking

Drive Dynamic braking is a method to slow down a servo system by dissipating the mechanical energy driven by the motor back EMF.

NOTE

Drive dynamic braking is not functional safe.

The drive has a built in advanced drive dynamic braking mode which operates fully in hardware. When activated, the drive powers the motor terminals with voltages to maximize the stopping force per amount of motor current. This advanced method forces all of the dynamic braking current to be stopping current and insures the fastest stopping per ampere of motor terminal current.

- When current is not being limited, the mechanical energy is being dissipated in the motor winding resistance.
- When current is being limited, energy is returned to the drive bus capacitors.
- The drive also limits the maximum dynamic braking motor terminal current by using the AXIS#.DBILIMIT parameter to insure that the drive, motor, and customer load do not see excessive currents/forces.

Whether and how the drive uses dynamic drive braking depends on AXIS#.DISMODE.

6.6.2 Regenerative braking

When the amount of returned energy from the motor builds the bus capacitor voltage up enough the drive activates the regenerative braking circuit to start dumping the returned energy in the regen resistor (also called regenerative resistor or brake resistor). The servo drive supports the ability to connect an external resistor depending on the application requirements.

NOTE

For more information on external regen resistors, see the (→ Accessories for Kollmorgen Essentials Drives # 128).

6.6.2.1 Functional description

1. Individual drives, not coupled through the DC bus link circuit (+DC, -DC)

When the energy fed back from the motor has an average or peak power that exceeds the preset level for the brake power rating, the drive generates the warning "W2010 Regen Energy Critical". If the power exceeds the set fault level, the regenerative circuit will switch off and the drive will disable.

2. Several drives coupled through the DC bus link (+DC, -DC)

NOTE

Only with group installation

With an external braking resistor, using the built-in regenerative circuit, several drives of the same series can be operated from a common DC-bus link (\rightarrow # 1), without any additional measures. 90% of the combined power of all the coupled drives is always available for peak and continuous power. If the power of the drive with the lowest switch-off threshold (resulting from tolerances) exceeds the set fault level, the regenerative circuit will switch off on that drive.

Switch-off on over voltage: With the regenerative circuit switched off, the returned energy is not dissipated and therefore the DC-bus link level increases. The drive reports an over-voltage fault if the DC-bus voltage threshold is

exceeded. When this happens, the drive power stage is immediately disabled and the load coasts to a stop with the fault message "F2006 Bus Over voltage".

NOTE

Observe the regeneration time (some minutes) after full load with peak brake power.

6.6.2.2 Technical data - 240V servo drives

Technical data for the regenerative circuit depends on the drive type and the mains voltage. Supply voltages, capacitance, and switch-on voltages are all nominal values.

Brake circuit

			AC Supply
Model	Rated data	Units	120V / 240V
	Regen start voltage at rated supply voltage	V	380
	Overvoltage limit	V	420
KED-6V03	Maximum regenerative duty cycle	%	35*
KED-6V06 KED-6V12	External regen resistor (recommended 33 Ω for KED-6V03/06 and 15 Ω for KED-6V12)	Ω	>23
	Continuous brake power, external resistor	kW	6V03/06: 1.5 6V12: 3
	Peak brake power, external (1s)	kW	5 / 14
KED-6V03	Absorption energy in capacitors (± 20%)	Ws	
KED-6V06	DC Bus Capacitance		1120
KED-6V12	Absorption energy in capacitors (± 20%)	Ws	9 / 35
	DC Bus Capacitance	μF	2460

^{*} depends on connected regen resistor power.

6.7 LED and Push-button B1

LED

The Kollmorgen Essentials Drive has an LED on its front side that indicates the status by a tri-color red-green-yellow light.



Color		State
	Dark	Control board unpowered
	Dark, yellow flash	Control board powered, disabled, no faults, warnings
	Dark, green flash	Control board powered, disabled, no faults, no warnings
	Dimly green	Control board powered but still booting up
	Green	Control board powered, enabled, no faults, no warnings
	Green/Red blink	Control board powered, downloading in progress
	Green, dark flash	Control board powered, dynamic brake active, no faults
	Green, yellow flash	Control board powered, enabled, no faults, warnings
	Yellow/Red blink (10 seconds)	Control board powered, DRV.BLINKDISPLAY command executed
	Red	Control board powered, faults
	Dark, red flash	Control board powered and running in Recovery mode

Push button B1

The Kollmorgen Essentials Drive has a push-button B1 on its top side.



B1 Functions	Description
Recovery	Press this button during power up to run in recovery mode.
Mode	This mode allows for a firmware file to be downloaded through WorkBench in case the
	firmware in the servo drive has been corrupted.

7 Mechanical Installation

7.1	Important Notes	43
	Guide to Mechanical Installation	
	Dimensions	.44

7.1 Important Notes



CAUTION High EMC Voltage Level!

Risk of electrical shock, if the servo drive (or the motor) is not properly EMC-grounded.

- Use electrically conductive mounting plates, e. g. made of aluminum or galvanized steel.
- · In unfavorable circumstances, use copper mesh tape between the earthing bolts and earth potential to deflect currents.



WARNING Ejection of molten particles!

If particles fall into the drive or the drive has been damaged, molten drive component particles may be ejected causing injuries. Shut down the drive and wear appropriate protective gear during maintenance work, troubleshooting and fault rectification.(→ # 26)

NOTICE

Protect the drive from impermissible stresses. In particular, do not let any components become bent or any insulation distances altered during transport and handling. Avoid contact with electronic components and contacts.

7.2 Guide to Mechanical Installation

You need at least the following tools to install your drive:

- M5 hexagon socket-cap screws (ISO 4762)
- · 4 mm hexagon ball head screwdriver
- No. 2 Phillips head screwdriver
- · Small slotted screwdriver

Your specific installation may require additional tools.

NOTICE

- Do not mount the drive right next to devices that produce magnetic fields. Strong magnetic fields can directly affect internal components. Install the drive with distance to such devices and/or shield the magnetic fields.
- Risk of burns from disconnecting the plug under load! Make sure that the screws are tightened.

Install the drive unit as follows:

- 1. Mount the drive in a closed control cabinet (ambient conditions (→ #35). The site must be free from conductive or corrosive materials. For the mounting position in the cabinet see (\rightarrow # 44).
- 2. Check that the ventilation of the drive is unimpeded and keep within the permitted ambient temperature (→ # 35). Keep the required space clearance above and below the drive (→ #44).
- 3. Ensure that there is an adequate flow of cool, filtered air into the bottom of the control cabinet, or use a heat exchanger (\rightarrow #35).

Notice: The drive will switch itself off in case of overheating.


- 4. If you are using a cooling system for the control cabinet, position the cooling system in a way that condensation water cannot drip onto the drive or peripheral devices.
- 5. Assemble the drive and power supply next to each other on the conductive, grounded mounting plate in the cabinet.
- 6. Ground the mounting plate, motor housing and CNC-GND of the control system. For EMC-compliant shielding and grounding see (\rightarrow # 51).

7.3 Dimensions

NOTE


Mounting: 2 x M5 hexagon socket screws to ISO 4762, 4mm hexagon ball head screwdriver

Parameter	Unit	6V03	6V06	6V12
Weight (without mating connectors)	kg	<1.1	<1.1	<2.0



NOTE

Outline width and height dimensions are measured on footprint level (mounting plate). Dimensions on the front plate are slightly smaller.



Model	Unit	Α	A1	В	B1	С	D	E	F	G	М
KED-6V03/KED-6V06	mm	169	225	210	215	60	195.4	5.8	11.4	8	≥0
KED-6V12	mm	202	262	239	243	70	224.5	5.8	11.4	8	≥0

8 Electrical Installation

8.1 Important Notes	46
8.2 Guide to Electrical Installation	47
8.3 Wiring	48
8.4 EMI Noise Reduction	51
8.5 Connection Overview	56
8.6 Power and Logic Voltage Supply (X3/X10)	64
8.7 DC Bus Link Connector X3	70
8.8 Regen Resistor Connector X3	72
8.9 Motor Power, Brake, and Feedback Connection	73
8.10 Industrial Ethernet Interface Connector X11/X12	80
8.11 Service Interface Connector X20	84
8.12 Digital I/O - X21	85

8.1 Important Notes



DANGER High Voltage up to 500V!

There is a danger of serious personal injury or death by electrical shock or electrical arcing. Capacitors can still have dangerous voltages present up to 5 minutes after switching off the supply power. Control and power connections can still be live, even if the motor is not rotating.

- Only install and wire the equipment when it is not live.
- Make sure that the cabinet is safely disconnected (for instance, with a lock-out and warning signs).
- Never remove electrical connections to the drive while it is live.
- Wait at least 5 minutes after disconnecting the drive from the main supply power before touching potentially live sections of the equipment (e.g. contacts) or undoing any connections.
- To be sure, measure the voltage in the DC bus link and wait until it has fallen below 50V.



WARNING Ejection of molten particles!

If particles fall into the drive or the drive has been damaged, molten drive component particles may be ejected causing injuries. Shut down the drive and wear appropriate protective gear during maintenance work, troubleshooting and fault rectification. (→ # 26)

NOTICE

Only professional staff who are qualified in electrical engineering are allowed to install the drive. Wires with color green with one or more yellow stripes must not be used other than for protective earth (PE) wiring.

NOTICE

Wrong mains voltage, unsuitable motor or wrong wiring will damage the servo drive. Check the combination of servo drive and motor. Compare the rated voltage and current of the units. Implement the wiring according to the matching connection diagram, see (→ # 57) and following.

Make sure that the maximum permissible rated voltage at the terminals L1, L2, L3 or +DC, -DC is not exceeded by more than 10% even in the most unfavorable circumstances (see IEC

NOTICE

Excessively high external fusing will endanger cables and devices. The fusing of the mains power and logic power must be installed by the user. Hints for the use of residual current devices (RCD) (→ #20).

NOTICE

Since the leakage current to PE is more than 3.5 mA, in compliance with IEC61800-5-1 the PE connection must either be doubled or a connecting cable with a cross-section >10 mm² must be used. Deviating measures according to regional standards might be possible.

NOTICE

The drive status shall be monitored by the PLC to acknowledge critical situations. We recommend wiring the ready to operate relay contact in series into the emergency off circuit of the installation. The emergency off circuit must operate the supply contactor.

NOTE

It is permissible to use WorkBench to change the settings of the drive. Any other alteration will invalidate the warranty.

8.2 Guide to Electrical Installation

Kollmorgen recommends to install the drive electrical system as follows:

- 1. Select cables in accordance with IEC 60204 (→ #48)
- 2. Install shielding and ground the drive.
 - For EMC-compliant shielding and grounding, see (→ #51).
 - Ground the mounting plate, motor housing and CNC-GND of the control system.
- 3. For functional safety information, see (→ # 104).
- 4. Wire the drive and connectors.

Observe the "Recommendations for EMI noise reduction": (→ #51).

- Wire the Safe Torque Off (STO) inputs into the emergency off circuit of the system.
- · Connect the digital control inputs and outputs.
- · Connect the motor hybrid cable
- · Connect shielding at both ends and ground cable to drive via cable clamp.
- · Connect the external regen resistor (with fusing).
- Connect the mains filter FN2060/FN2090/FN3040/FN3287 for second environment requirements to product category C2.
- · Connect the auxiliary voltage supply
- Connect the main electrical supply.
 Check maximum permitted voltage value (→ # 36).
- Check proper use of residual current devices (RCD): (→ # 20).
- Connect the PC (→ #84) for setting up the drive.
- 5. Check the wiring against the wiring diagrams:

Wiring reference	Page
Overview	(→ # 57)
Connector pinout	(→ # 59)
Mains power supply	(→ # 65)
Logic power supply	(→ # 69)
DC Bus Link	(→ # 70)
External Regen Resistor	(→ # 72)
Motor cable connection	(→ # 74)
Motor Holding Brake	(→ # 76)
Feedback Connection	(→ # 79)
Industrial Ethernet interface	(→ # 80)
Service interface	(→ # 84)
Digital I/O	(→ # 85)
Functional Safety option 1	(→ # 112)

8.3 Wiring

8.3.1 General



↑ DANGER High Voltage up to 500V!

There is a danger of serious personal injury or death by electrical shock or electrical arcing.

- · Only install and wire the equipment when it is not live, that is, when neither the electrical supply nor the 24V auxiliary voltage nor the supply voltages of any other connected equipment is switched on.
- Make sure that the cabinet is safely disconnected (for instance, with a lock-out and warning) signs). The individual voltages are switched on for the first time during setup.

NOTICE

Only professional staff who are qualified in electrical engineering are allowed to install the servo drive. Wires with color green with one or more yellow stripes must not be used other than for protective earth (PE) wiring. When installing or replacing cables, use only standardized components, which comply to the cable and wire requirements (→ #48).

NOTE

The chassis ground symbol (see (Symbols Used, → # 10)) indicates that you must take care to provide an electrically conductive connection with the largest feasible surface area between the unit indicated and the mounting plate in the control cabinet. This connection is for the effective grounding of HF interference, and must not be confused with the PE-symbol (PE = protective earth, safety measure as per IEC 60204).

8.3.2 Mating connectors

Mating connector overview

#	Description	Туре	Max. Cross Section
X1	Motor, holding brake	Connector, 4 pol. power	10 mm², 8 awg
Х3	Mains power, regen resistor, DC-Bus	Connector or T-type, 8 pol.	6 mm ² , 10 awg
X10	24V power supply, STO input	Connector, 8 pol.	1.5 mm², 14 awg
X21	I/O control signals	Connector, DB9 (9-pin D-sub)	1.5 mm², 16 awg
X23	Motor feedback	2-pin connector	

8.3.3 Cable and Wire Requirements

The Kollmorgen Essentials Drive has one motor cable (X1) which you can use for all motors.

For information on the chemical, mechanical, and electrical characteristics of the cable please refer to the (→ # 125) section or contact our customer support.

Motor cable (X1):

- Max. cable length: 25m / 50m with choke
 Notice: Cables should not exceed the maximum lengths. The recommended maximum cable length of motor cables depends on the used cable material and the feedback type. Cable functionality is only guaranteed up to the maximum length when using unmodified Kollmorgen engineered cables.
- · Supports SFD-M and SFD3

I/O cable (X21):

- Maximum distance for unshielded I/O lines is 3m inside the cabinet.
- If the I/O cable leaves the cabinet, ensure EMC shielding.

8.3.3.1 Cable cross sections and requirements

The tables below describe the recommended interface cross sections and cable requirements related to Kollmorgen Essentials Drive in accordance with IEC 60204.

Power Cables		Cross (Section US	Remarks
Mains supply	3 A: 6 A: 12 A:	1.5 mm ² 1.5 mm ² 1.5 mm ² 2.5 mm ² 6 mm ²	14 awg 14 awg 14 awg 14 awg 14 awg 10 awg	600 V rated, minimum 75°C
24 V supply	max.	1.5 mm ²	14 awg	Single core Flexible Class 5
DC bus link, Regen resistor	3/6 A: 12 A: 24 A:	1.5 mm ² 2.5 mm ² 6 mm ²	14 awg 14 awg 10 awg	1000 V rated, min. 75°C, shielded for lengths >0.20 m
Digital I/Os		0.5 mm ²	20 awg	single core

8.3.3.2 Kollmorgen Essentials Hybrid Cable Wiring Specifications

Cable	Туре	Cross Section [mm ²]	Current Carrying Capacity	Remarks
				1000 V rated, 80°C
H2-51-015- A5-xxxx00	Power + Brake + SFD-M/ SFD3	(4x1.5+(2x0.34)+(2x0.75))	10.1A < l0rms ≤ 13.1A	Current carrying capacity acc. to IEC 60204-1:2006 Table 6,
H2-51-025- A5-xxxx00		(4x2.5+(2x0.34)+(2x1.0))	13.1A < l0rms ≤ 17.4A	4 power lines & 2 brake lines & 2 SFD-M/SFD3 signal lines

8.3.4 Protective Earth Connection


Protective Earth connection of the system components is a safety measure per IEC 60204. Ensure the proper grounding of all components with the PE rail in the control cabinet as reference potential. Connect each ground individually with the intended grounding cable (neutral point connection).

The leakage current from Kollmorgen Essentials Drive against PE is more than 3.5 mA. In accordance with EN 61800-5-1, the PE connection must therefore either be double implemented or a connection cable with >10 mm² cross-section used.

In order to keep the impedance as low as possible, we recommend a copper earthing strap for the PE connection on the PE block.

NOTE

Wire the PE connections immediately after installing the devices as the first electrical connection. Now you insert all the other lines and connectors. For disassembly, release the PE connections as the last connection.



NOTE

For the use of residual current protective devices (RCD), refer to (→ # 1).

8.4 EMI Noise Reduction



CAUTION Electromagnetic fields!

Electromagnetic radiation may lead to potential hazardous danger (warming, failure of implants), when acting on electrically conductive materials.

- · Work on the electrical installation may only be performed by trained and qualified personnel, in compliance with the regulations for safety at work, and only with switched off mains supply and secured against restart.
- Do not remove grounding, equipotential bonding and radiation-reducing shields.

8.4.1 Reducing EMI noise

With the help of the following instructions, you can reduce electrical interference in the application:


- Ensure good connections between the cabinet components. Connect the back panel and cabinet door to the cabinet body using several conductive braids. Never rely on hinges or mounting bolts for ground connections.
- · Ensure good ground connection. Connect from cabinet to proper earth ground. Ground leads should be the same gauge as the leads to main power, but must cover the regional legal requirements, example (→ #50).
- Use Kollmorgen cables. Route power and control cables separately, Kollmorgen recommends a distance of at least 200mm to improve interference immunity.
- Ground the shielding at both ends. Ground all shielding with large areas (low impedance), with metalized connector housings or shield connection clamps wherever possible. For cables entering a cabinet, connect shields on all 360° of the cable. Never connect a simple "pigtail." For more information on shielding concepts, (→ #52).
- With separate mains filter, maintain separation of leads entering and exiting the mains filter (line power filter). Locate the filter as close as possible to the point where the incoming power enters the cabinet. If it is necessary for input power and motor leads to cross, cross them at 90°.
- Observe cable length limits. Maximum distance for unshielded I/O lines is 3m inside the cabinet. If the I/O cable leaves the cabinet, it must be EMC shielded.
- Do not extend feedback lines and hybrid cables, since the shielding would be interrupted and the signal processing may be disturbed. Install all feedback cables with an adequate cross-section, per IEC 60204 (→ #49) and use the requested cable material to reach maximum cable length.
- · Splice cables properly. If you need to divide cables, use connectors with metal backshells. Ensure that both shells connect along the full 360° of the shields.
- Shield cables between drives and filters or external regen resistors. Install all power cables with an adequate cross-section per IEC 60204 (→ #49)and use the requested cable material to reach maximum cable length.

8.4.2 Shielding with External Shielding Busbar

Kollmorgen recommends a star point shield connection, for example, with a shielding busbar.

8.4.2.1 Shielding Concept

Example with Kollmorgen Essentials Drive, EMC filter and external regen resistor.




8.4.2.2 Shielding Busbar





The power cable shields (line in, motor cable, external regen resistor) can be routed to an additional busbar via shield clamps.


Kollmorgen recommends using Weidmüller KLBÜ shield clamps.

A possible scenario for setting up a busbar for the above shield clamps is described below.










- 1. Cut a busbar of the required length from a brass rail (cross-section 10 x 3mm) and drill holes in it as indicated. All shield clamps required must fit between the drill holes.
 - **CAUTION:** Risk of injury due to the spring force of the coil spring. Use pincers.
- 2. Squeeze together the coil spring and the supporting plate and push the busbar through the opening in the holder.
- Mount the busbar with the shield clamps fitted on the assembly plate. Use either metal spacer bushes or screws with nuts and accessories to maintain a spacing of 50mm. Earth the busbar using a single conductor with a cross-section of at least 2.5mm².
- 4. Strip the external cable sheath to a length of approx. 30mm, taking care not to damage the braided shield. Push the shield clamp up and route the cable to it via the busbar.

NOTICE: Make sure there is good contact between the shield clamp and the braided shield.

8.4.3 Shielding Connection to the Servo Drive

8.4.3.1 Shielding Concept



8.4.3.2 Grounding Shield Connection Clamp

A grounding shield clamp is mounted to the servo drive.



For extra grounding in high EMI environments, add a tie across the prongs of the clamp to ensure a very tight ground connection.


Kollmorgen Essentials Cables are supplied with the shield connection clamp. Push the cable into the spring clamp so that the exposed cable shield makes good contact with the shield clamp.

For strain relief, tighten a metal cable tie around the insulated cable and the notch toward the bottom of the shield.

8.5 Connection Overview


8.5.1 Connector Position - Kollmorgen Essentials Drive 6V03...12

The graphic shows the servo drive with supply voltage 110 to 240V.




8.5.2 Wiring Overview

8.5.2.1 KED-SPM-6V03 and KED-SPM-6V06 Connection Diagram



8.5.2.2 KED-SPM-6V12 Connection Diagram



8.5.3 Connector Pinout

Information to wiring, mating connectors and cables (→ #48).

8.5.3.1 X1: Motor power and brake

X1 specifications

Pinout diagram	Specifications				
	Motor power, motor brake				
X1 • BR- BR+ PE U V W O	 KED-6V03/KED-6V06: 6 pin, pitch 5.08mm 6 slotted conductor screws Tightening torque for mounting screws: 0.5-0.6Nm 2 locking screws: 0.3Nm KED-6V12: 				
BR-BR+PE X1 U V W	 7 pin, pitch 6.35mm Tightening torque for mounting screws: 0.3Nm No screw contacts 				

X1 pinout for 6V03/06 models

Pin	Signal	Description			
1	BRAKE-	Negative connection to the mechanical brake			
2	BRAKE+	Positive connection to the mechanical brake			
3	PE	Protective earth			
4	U	Connection to motor phase			
5	V	Connection to motor phase			
6	W	Connection to motor phase			

X1 pinout for 6V12 models

Pin	Signal	Description
1	BRAKE-	Negative connection to the mechanical brake
2	BRAKE+	Positive connection to the mechanical brake
3	PE	Protective earth
4		
5	U	Connection to motor phase
6	V	Connection to motor phase
7	W	Connection to motor phase

8.5.3.2 X3: Mains, regen resistor, DC-Bus

X3 specifications

Pinout diagram	Specifications				
X3 -RB	 Mains supply, external regen resistor, DC bus KED-6V03/KED-6V06: 7 pin, pitch 5.08mm Tightening torque for mounting screws: 0.3Nm Tightening torque for ladder screws: 0.5-0.6Nm KED-6V12: 				
X3	 8 pin, pitch 6.35mm No screw contacts 				

X3 pinout for 6V03, 6V06 servo drives

Pin	Signal	Description			
1	-RB	Negative end of braking resistor*			
2	+DC_BUS	ositive DC bus; positive end of braking resistor*			
3	-DC_BUS	Negative DC bus			
4	AC_L3	Mains input phase			
5	AC_L2	Mains input phase			
6	AC_L1	Mains input phase			
7	PE	Protective earth			

X3 pinout for 6V12 servo drives

Pin	Signal	Description
1	-RB	Negative end of braking resistor*
2	+DC_BUS	Positive DC bus; positive end of braking resistor*
3	+DC_BUS	Positive DC bus; positive end of braking resistor*
4	-DC_BUS	Negative DC bus
5	AC_L3	Mains input phase
6	AC_L2	Mains input phase
7	AC_L1	Mains input phase
8	PE	Protective earth

^{*}mounted externally

8.5.3.3 X10: 24 VDC and STO input

X10 specifications

Pinout diagram		Specifications
X10 24V -	, - + + B	 4x2 pin, pitch 3.5mm Spring clamps 24 VDC supply voltage, STO inputs
310		

X10 pinout

Signal	Pin	Pin	Signal
GND_24V	1A	1B	GND_24V
+24V	2A	2B	+24V
+24V	3A	3B	+24V
STO-A	4A	4B	STO-B

8.5.3.4 X11/12: Industrial Ethernet

X11/12 specifications

Pinout diagram	Specifications		
X11/12	 RJ45 with built-in green/red dual-color LED EtherCAT, EtherNet/IP, PROFINET Interface Details: (→ # 80) 		

X11/12 pinout

Pin	Signal	Description	Pin	Signal	Description
1	Tx+	Transmit +	5	Term.	Termination
2	Tx-	Transmit -	6	Rx-	Receive -
3	Rx+	Receive +	7	Term.	Termination
4	Term.	Termination	8	Term.	Termination

8.5.3.5 X20: Service

X20 specifications

Connector at computer	Connector at servo drive	Length	Image	Right-angle connector at servo drive	Spec	Туре
A male	C male	< 2m	N. Carlotte	≽ ≜	USB 2.0	Data transfer and charge
С	С	< 2m	=	<u> </u>	USB 2.0	Data transfer and charge

8.5.3.6 X21: I/O

X21 specifications

Pinout diagram	Specifications		
	 DB9 (9-pin D-sub), female Locking screws, tightening torque: 0.4Nm (3.5inlbs) 4 Digital-In, 2 Digital-Out 		

X21 pinout

Pin	Signal	Description	
1	DIN1	High-speed digital input, 24V signalling	
2	DIN2	High-speed digital input, 24V signalling	
3	DIN3	Slow digital input, 24V signalling	
4	DIN4	Slow digital input, 24V signalling	
5	GND_IO	Common for digital inputs	
6	DOUT1+	Digital output 1, positive connection	
7	DOUT1-	Digital output 1, negative connection	
8	DOUT2+	Digital output 2, positive connection	
9	DOUT2-	Digital output 2, negative connection	

8.5.3.7 X23: Single-cable Feedback

X23 specifications

Pinout diagram	Specifications
	IEC 63171-6 connector
X23	SFD-M/SFD3 feedback


X23 pinout

Pin	Signal	Description
1	DP+	Data+ with +12V
2	DP-	Data- with 0V

8.6 Power and Logic Voltage Supply (X3/X10)

8.6.1 Electrical Supply Connection

8.6.1.1 Connection to various mains supply networks - 240V servo drive



8.6.2 Mains Power Supply Connector X3

Servo drives in the Kollmorgen Essentials Drive series can be supplied as follows:

240V servo drive with 3 and 6A_{rms}

1, 2 or 3 phase industrial AC supply networks (TN-S or TT, see KSN): (→ # 36)

240V servo drive with 12A_{rms}

3 phase industrial AC supply networks (TN-S or TT, see KSN): (→ # 36)

For connection to corner grounded delta supply networks contact Kollmorgen customer support.

Periodic overvoltages between phases (L1, L2, L3) and the PE/housing of the servo drive must not exceed 1,000V peak. In accordance with IEC 61800, voltage spikes ($< 50 \,\mu s$) between phases must not exceed 1,000V. Voltage spikes ($< 50 \,\mu s$) between a phase and the PE/housing must not exceed 2,000V.



- 8/4 pin, pitch 7.62/10.16mm
- · Wiring example:
 - 1 phase AC supply (→ #66)
 - 2 phase AC supply (→ #66)
 - 3 phase AC supply (→ # 67)



- Mating connector data (→ #48)
- Fusing with different system structures (→ # 68)


Pin	Label	Signal	1~ Supply	2~Supply	3~ Supply
1	PE	PE	Protective earth	Protective earth	Protective earth
2	L1	L1	Phase L1	Phase L1	Phase L1
3	L2	L2	Neutral N	n.c.	Phase L2
4	L3	L3	n.c.	Phase L2	Phase L3

For DC supply: observe notes (\rightarrow # 65).

8.6.2.1 Wiring examples mains power supply


One phase AC mains (240V servo drive)

- · Directly to one phase supply network with neutral line.
- Activate single phase supply (VBUS.THREEPHASE = 0).
- Set VBUS.ACNOMINAL to desired nominal AC line voltage for lines other than nominal rated VAC.
- · For complete information refer to WorkBench Help.
- You need to provide AC line filtering. Use filter type FN2090 and refer to the (→ Accessories for Kollmorgen Essentials Drives # 128) for more information. Use a shielded cable between filter and drive.




Two phases AC mains (240V servo drive)

- · Directly to two-phase supply network without neutral line.
- Activate single phase supply (VBUS.THREEPHASE = 0).
- Set VBUS.ACNOMINAL to desired nominal AC line voltage for lines other than nominal rated VAC.
- For complete information refer to WorkBench Help.
- You need to provide AC line filtering. Use filter type FN2090 and refer to the (→ Accessories for Kollmorgen Essentials Drives # 128) for more information. Use a shielded cable between filter and drive.



Three phases AC mains (240V servo drive)


- Directly to 3-phase supply network.
- Activate 3-phase supply (VBUS.THREEPHASE = 1).
- Set VBUS.ACNOMINAL to desired nominal AC line voltage for lines other than nominal rated VAC.
- · For complete information refer to WorkBench Help.
- You need to provide AC line filtering. Use filter type FN2090 and refer to the (→ Accessories for Kollmorgen Essentials Drives # 128) for more information. Use a shielded cable between filter and servo drive.
 - 240V servo drive with 3 and 12 A_{rms}:
 Motor cable < 10 m: use filter FN 2090 in industrial environment, category C2.
 Motor cable ≥ 10 m: use filter FN 2060 in industrial environment, category C3.



8.6.2.2 Fusing

Fuse types	Description
US fuses	 Class J, 600VAC, 200kA SCCR, time-delay must be UL and CSA listed Alternate fuses to Class J must have similar or better Ip and I²T performance per UL 508A SB4.2 at max. 5kA SCCR rating.
EU fuses	gS or gG, 400/500V, time-delaymax. 10kA SCCR
Fuse holders	Use finger-safe fuse holders according to EN 60529 in combination with the standard fuse blocks.

AC supply, single servo drives, line fusing



- F1, F2, F3: depends on sum of application's required input currents and cabinet requirements.
- Filters for special EMC requirements only (→ # 129).
- FN1, FN2, FN3 recommended rating see table below:

Servo drive Model	FN1, FN2, FN3: Ampere rating	Example class J Eaton Bussmann	Example class J Mersen
KED-6V03 KED-6V06	10A (Time-Delay)	LPJ10SP, DFJ10	AJT10, HSJ10
KED-6V12	15A (Time-Delay)	LPJ15SP, DFJ15	AJT15, HSJ15

8.6.3 Auxiliary Voltage Power Supply Connector X10

The following diagram describes external 24 VDC power supply (PELV). The required supply current rating depends on the use of motor brake (\rightarrow # 36).



- 2x4 pin, pitch 3.5mm
- T-type mating connector data (→ #48)
- · Undervoltage fault limit 19V
- · Overvoltage fault limit 30V

For control supply current requirement specifications see section (→ #38).

8.6.3.1 Fusing

Use 24 VDC supply manufacturer's recommendation for fusing.


8.6.3.2 Wiring example 24 VDC supply

Maximum current for one string of daisy-chained X10T connectors is 8A. The sum of the control currents of the connected servo drives should not exceed 8A.

Possible connections:

- · 5 servo drives in line, no brakes
- · 3 servo drives in line, with brakes
- · in a ring connection the number of servo drives can be doubled

Wiring example with three phase power supply unit:




8.7 DC Bus Link Connector X3

The DC bus link can be connected in parallel so that the power returned from slowing down motors is divided between all the servo drives that are connected to the same DC bus link circuit. Every servo drive must have its own power connection to mains voltage sharing the same branch, over current protection devices, even if the DC bus link is used. Servo drives working generatively very often should be placed beside servo drives, which need energy. That reduces current flow on longer distances.

NOTICE

The servo drives can be destroyed if DC bus link voltages are different. Only servo drives with mains supply that share the same AC branch, over current protection devices (identical mains supply voltage) may have the DC bus links interconnected. Interconnection of DC bus links works best in systems powered by 3-phase AC or DC power. Consult Kollmorgen for DC bus linking with single phase AC power input.



• Mains supply, external regen resistor, DC bus

KED-6V03/KED-6V06:

- 7 pin, pitch 5.08mm
- Tightening torque for mounting screws: 0.3Nm
- Tightening torque for ladder screws: 0.5-0.6Nm

KED-6V12:


- 8 pin, pitch 6.35mm
- No screw contacts

Mating connector data (→ # 48)

Pin	Label	Signal	Description
7	+DC	+DC	DC Bus link positive
8	-DC	-DC	DC Bus link negative

8.7.1 DC Bus sharing between Kollmorgen Essentials Drives

All servo drives are connected to AC with the same number of phases and the same voltage.



When several units are connected to the same AC mains the units need to be able to share a common DC Bus via the X3 connector, as shown in the following table:

Further explanation:

One DC Bus can be shared by 2 KED-6V03...06 or 3 KED-6V12.


NOTE Connect the regen resistor to the servo drive with the highest current rating.

8.8 Regen Resistor Connector X3

For technical data on the regenerative brake circuit refer to (→ #38).

NOTE

You are responsible for fusing (such as fusible cut-outs or power switches).



• Mains supply, external regen resistor, DC bus

KED-6V03/KED-6V06:

- 7 pin, pitch 5.08mm
- Tightening torque for mounting screws: 0.3Nm
- Tightening torque for ladder screws: 0.5-0.6Nm

KED-6V12:

- 8 pin, pitch 6.35mm
- No screw contacts
- Mating connector data (→ # 48).
- Refer to the WorkBench online help for parameter setting (REGEN.EXT, REGEN.REXT, REGEN.WATTEXT)

Pin	Label	Signal	Description
6	Re	-RB	external Regen resistor -
7	+DC	+RBext	external Regen resistor +

8.9 Motor Power, Brake, and Feedback Connection


The drive is able to protect the connected motor from overloading, if the parameters are set correctly and the thermal protection sensor is connected and supervised. With Kollmorgen motors the valid data are automatically set by the WorkBench motor database. Refer to parameter AXIS#.MOTOR.RTYPE for supported thermal sensors.



The dynamic voltage rise can lead to a reduction in the motor operating life and, on unsuitable motors, to flashovers in the motor winding.

- Only install motors with insulation class F (acc. to IEC60085) or above.
- Only install cables that meet the requirements (→ # 49).

8.9.1 Motor Connectivity Example




For grounding shield connection, see (→ #54)

8.9.2 Motor Cable Connection

Motors with two wire feedback systems like SFD-M can be connected to the servo drive by using a single Kollmorgen hybrid cable.

8.9.2.1 Motor power and brake connector X1



- X1 (Feedback 1)
 - Motor Power: 4 pin, pitch 7.62mm
 - Motor Brake: 2 pin, pitch 3.81mm
 - Motor Feedback: 2 pin, pitch 3.81mm
- Cable length and mating connector data: (→ # 48)
- Use Kollmorgen cables
- Feedback type: SFD-M
 - Rated voltage 11V.
 - Rated current is 350mA

8.9.2.2 Motor leads to servo drive connector X1

X1 pinout for 6V03/06 models

Pin	Signal	Description
1	BRAKE-	Negative connection to the mechanical brake
2	BRAKE+	Positive connection to the mechanical brake
3	PE	Protective earth
4	U	Connection to motor phase
5	V	Connection to motor phase
6	W	Connection to motor phase

X1 pinout for 6V12 models

Pin	Signal	Description
1	BRAKE-	Negative connection to the mechanical brake
2	BRAKE+	Positive connection to the mechanical brake
3	PE	Protective earth
4		
5	U	Connection to motor phase
6	V	Connection to motor phase
7	W	Connection to motor phase

8.9.2.3 Motor feedback cable connector to servo drive feedback connector X23

Pin	Signal	Description
1	COM+	SFD-M Positive Signal
2	COM-	SFD-M Negative Signal

8.9.3 Motor Holding Brake Connection

A 24V holding brake in the motor can be controlled directly by the servo drive. For proper function, check voltage drop, measure voltage at brake input and check brake function (on and off).

The brake is powered by the 24V auxiliary supply on X10. Minimum and maximum brake current see Electrical Data (\rightarrow # 37).



<u>∧</u>WARNING

No functional safety!

Serious injury could result when the load is not properly blocked. The internal brake function does not ensure functional safety.


- The Hardware Enable does not initiate a controlled stop but switches off the power stage immediately.
- Set parameter AXISx.MOTOR.BRAKEIMM to 1 with vertical axes, to apply the brake immediately after faults or Hardware Disable.

Pinout for motor brake X1

Pin	Signal	Description
B+	BR+	Brake positive line
B-	BR-	Brake negative line


Wiring

Usually the brake line is part of the Kollmorgen cable connection to X1 (\rightarrow #74).



Functionality

The brake function must be enabled through a parameter. The diagram below shows the timing and functional relationships between the controlled stop signal, speed, and braking force. All values can be adjusted with parameters; values in the diagram are default values.



The servo drive speed setpoint is internally driven down an adjustable ramp (AXISx.CS.DEC) to 0 V.

With default values the output for the brake is switched on when the speed has reached 5 rpm (AXISx.ZEROV) for at least 6 ms (AXISx.ZEROT). The rise (t_{brH}) and fall (t_{brL}) times of the holding brake that is built into the motor are different for the various types of motor.

8.9.4 Feedback Connector X21

The X21 port provides input for command or feedback options:

- · Step/Direction
- CW/CCW
- · Incremental Encoder without index or halls

The servo drive provides 4 digital inputs and 2 digital outputs on the X21 DB9 (9-pin D-sub) port. Pins 1 and 2 are fast input, isolated, sink, type EN 61131-2 type 1 and are capable of quadrature feedback input.


NOTICE

Maximum distance for unshielded I/O lines is 3m inside the cabinet. Ensure EMC shielding if the I/O cable leaves the cabinet.

NOTICE

The X21 digital inputs are 24V and not compatible with 5V logic.

8.9.4.1 X21 Feedback Connector Pinout



X21 Pin	Incr. Encoder FB2.IDENTIFIED 11	Step/Direction FB2.IDENTIFIED 13	Incr. Encoder FB2.IDENTIFIED 14
1	Α	Step	CW
2	В	Direction	CCW
4	24 V _{DC}	24 V _{DC}	24 V _{DC}
5	Common (DGND)	Common (DGND)	Common (DGND)

8.9.5 Feedback Connector X23

The Kollmorgen Essentials Drive offers one feedback channel.

The usage of this feedback channel may be freely configured in the software, subject only to a few restrictions that are not physically sensible.

Cable length

Feedback Type	Max. cable length
SFD-M	25m / 50m*
SFD-3	25m / 50m*

^{*}with choke


Specifications



- 2-wire connection with 12V signal
- SFD3 and SFD-M are supported
- Up to 350mA available from 11V...12V at the servo drive

Wiring diagram

The diagram below shows the connection of the two-wire SFD3/SFD-M feedback system.



8.10 Industrial Ethernet Interface Connector X11/X12

The Industrial Ethernet interface has two RJ45 connectors with two associated LEDs at each port.



- RJ45 with built-in green/red bi-color LED
- EtherCAT®
- EtherNet/IP™
- PROFINET®

NOTICE

Industrial Ethernet interface X11/X12 pinout depends on the protocol used. Refer to the matching fieldbus communication manual.

Link/Activity LED

The link/activity LED at each port is green.

LED	Meaning
Off	no connection
Lit	LINK: connection
Flashes	activity (packets detected)

8.10.1 EtherCAT®

The Kollmorgen Essentials Drive can be connected as a slave to the EtherCAT® network (CoE) by using RJ45 connectors X11 (out port) and X12 (in port). The communication status is indicated by the built-in connector LEDs.

	Port	LED Indicator	Function
			Returns potentials communication failures:
		ER "ERROR"	Off = No Error
			Blinking = Invalid configuration
	X11 Out		Single Flash = Local error
	Out		Double Flash = Process data watchdog
문		Link/	On/Blinking: Physical link/Data Traffic on.
X11 Out ¥		Activity	Static off: No link.
		RN "RUN"	Returns the device state:
X12	X12		Off = INIT
In Š			Blinking = PRE-OPERATIONAL
			Single Flash = SAFE-OPERATIONAL
	In		On = OPERATIONAL
			Flickering = Initialization or BOOTSTRAP
		Link/	On/Blinking: Physical link/Data Traffic on.
		Activity	Static off: No link.


Cables

Use standard Ethernet cables with at least these characteristics:

- Category 5 (CAT5) or better according to EN 50173 or ISO/IEC 11801
- Shielding: S/FTP or better

Bus topology example (EtherCAT®)

We suggest to use Kollmorgen ENCP cables. For more possible system solutions refer to the WorkBench Online Help.



Communication profile

For EtherCAT® communication profile description refer to the manual AKD2G EtherCAT® Communication.

8.10.2 PROFINET

The Kollmorgen Essentials Drive can be connected as a slave to a PROFINET network by using RJ45 connectors X11 (Port 2) and X12 (Port 1). PROFINET RT or IRT protocols can be used.

Address

The Industrial Ethernet address is set automatically.


LEDs

The communication status is indicated by the built-in connector LEDs.

		Port	LED Indica	ator	Function
		X11 Out	BF		ON = No Configuration, low speed, no link
					OFF = No Error
					Flashing 2Hz = No data exchange
			Link/ Activity		ON = Connection to the Ethernet
X11	吊吊				OFF = No connection to the Ethernet
Out	■¥				Flashing = Sends/receives Ethernet frames
X12	LINK SF L	X12	SF		ON = Watchdog timeout; channel / generic / extended diagnosis present; system error
In					OFF = No Error
					Flashing 2Hz = DCP signal service is initiated via the bus
		In			ON = Connection to the Ethernet
			Link/ Activity		OFF = No connection to the Ethernet
			Activity		Flashing = Sends/receives Ethernet frames

Bus topology example (PROFINET)

We recommend to use ENCP cables. For more possible system solutions refer to the WorkBench Online Help.



Communication profile

For PROFINET communication profile description refer to the manual AKD2G PROFINET Communication.

8.10.3 EtherNet/IP

The Kollmorgen Essentials Drive can be connected as a slave to an EtherNet/IP network by using RJ45 connectors X11 (Port 2) and X12 (Port 1).


LEDs

The communication status is indicated by the built-in connector LEDs.

	LED Indicator	Status	Function
		On	Connection
		Flashing	No Connection
	Natural Status (NS)	Off	No power, No IP Address
	Network Status (NS)	On	Duplicate IP Address
		Flashing	Connection Time-Out
NS NS		Flashing	Self-Test
X11	Limb./A seinite.	On	Ethernet Connection
Out	Link/Activity	Off	No Ethernet Connection
™ S		On	Device Operational
X12 In		Flashing	Standby
In Z	•	Off	No Power
	Module Status (MS)	On	Unclearable Fault
		Flashing	Clearable Fault
		Flashing	Self-Test
	1:-1./4:: ::	On	Ethernet Connection
	Link/Activity	Off	No Ethernet Connection

Bus topology example (EtherNet/IP)

We suggest to use Kollmorgen ENCP cables. For more possible system solutions refer to the WorkBench Online Help.



8.11 Service Interface Connector X20

The Service Interface X20 provides USB connection to a PC running WorkBench software for configuration, firmware updates and diagnostics.



NOTE

Rubber plug

Insert the rubber dust plug into the X20 USB-C slot when no cable is inserted, in order to protect it against particle/dust ingress and to protect against impairment of connection quality.

The rubber plug is included with the servo drive.


8.11.1 Cables

Use standard USB-C data cables up to 2m length. One end of the cable must have a USB-C connector to plug into the servo drive. The other end which connects to a PC or USB hub may be USB-C or USB-A.

NOTICE

Use data cables

Some USB cables are only designed for providing charging power. These will not work for communicating with the servo drive.



8.11.2 Ferrites

In an electrically noisy environment, ferrites on the USB cable may be helpful to avoid inconsistent communications. A ferrite is most helpful on the PC end of the cable. Snap-on ferrite cores and USB cables with built-in ferrites are commonly available.

8.12 Digital I/O - X21

The servo drive provides 4 digital inputs and 2 digital outputs on the X21 DB9 (9-pin D-sub) port.

All inputs and outputs can be used to initiate pre-programmed actions. A list of actions is included in WorkBench. If an input, or output is programmed, it must be saved to the servo drive.




Maximum distance for unshielded I/O lines is 3m inside the cabinet. Ensure EMC shielding if the I/O cable leaves the cabinet.

NOTE


Depending on the selected function, the inputs are high or low active. Set the digital input filter in WorkBench to change sensitivity of the inputs (see Online Help).

Type 1 digital inputs according to IEC61131-2 have the following input voltage current characteristics:



Channel	Туре	Explanation
DIN1, DIN2	Fast, 24V, 61131-2 Type 1 input	An isolated, current sinking digital input referred to GND_24V. The threshold and current characteristics are IEC61131-2 Type 1. The activation delay (0->1) is <1µs and the de-activation delay (1->0) is <1µs. Additional filtering also takes place in the FPGA with selectable filter values. Can also support quadrature feedback.
DIN3, DIN4	Slow, 24V, 61131-2 Type 1 input	An isolated, current sinking digital input referred to GND_24V. The threshold and current characteristics are IEC61131-2 Type 1. The activation delay (0->1) is on the order of 5µs and the de-activation delay (1->0) is on the order of 500µs. Additional filtering also takes place in the FPGA with selectable filter values.
DOUT1, DOUT2	Slow, 24V, Digital output	An isolated pair of volt-free contacts. Collector (+) and emitter (-) brought out to separate pins. 100mA rated with latch off upon over-current.

8.12.1 X21 Connector Pinout



9 Setup

9.1	Important Notes	88
	Guide to Servo Drive Setup	
	Switch-On and Switch-Off Behavior	
9.4	Fault and Warning Messages	102
	Troubleshooting	

9.1 Important Notes

NOTICE

Only professional personnel with extensive knowledge in the fields of electrical engineering and drive technology are allowed to test and set up the drive.



DANGER

Lethal Voltage!

There is a danger of serious personal injury or death by electrical shock. Lethal danger exists at live parts of the device.

- Built-in protection measures such as insulation or shielding may not be removed.
- Work on the electrical installation may only be performed by trained and qualified personnel, in compliance with the regulations for safety at work, and only with switched off mains supply, and secured against restart.
- In normal operation, the cabinet door must be closed and the device must not be touched.



WARNING Automatic Restart!

Risk of death or serious injury for humans working in the machine. The drive might restart automatically after power on, voltage dip or interruption of the supply voltage, depending on the parameter setting. If parameter AXIS#DEFAULT is set to 1,

- then place a warning sign ("WARNING: Possible Automatic Restart" or similar) to the machine.
- ensure, that power on is enabled, while humans are in a dangerous zone of the machine.



WARNING Ejection of molten particles!

If particles fall into the drive or the drive has been damaged, molten drive component particles may be ejected causing injuries. Shut down the drive and wear appropriate protective gear during maintenance work, troubleshooting and fault rectification. (→ # 26)



CAUTION High Temperature!

Risk of minor burns. The heat sink of the drive can reach temperatures up to 80°C in operation.

- Check the heat sink temperature before handling the drive.
- Wait until the heat sink has cooled down to 40°C before touching it.

NOTICE

NOTE

If the servo drive has been stored for more than 1 year, re-form the capacitors in the DC bus link circuit. Re-forming procedures are described in the Kollmorgen Support Network (Forming). Additional information on setting up the equipment:

- Programming parameters and control loop behavior are described in the Essentials Portal.
- The setup of any Industrial Ethernet is described in the corresponding manual.

9.2 Guide to Servo Drive Setup

Setup your servo drive in two major steps:

- 1. Servo drive setup (this section). This section presents an example to test the drive initially. If the servo drive (servo motor, feedback, control circuits, I/Os) is well parameterized, then proceed with step 2.
- 2. Functional Safety setup (→ #1).

9.2.1 Initial Procedure for Servo Drive Test


9.2.1.1 Unpacking, mounting, and wiring the Kollmorgen Essentials Drive

- 1. Unpack the servo drive and accessories.
- 2. Mount the servo drive.
- 3. Wire the servo drive or apply the minimum wiring for servo drive testing as described below.
- 4. Make sure you have on hand the following information about the servo drive components:
 - · rated mains supply voltage
 - motor type (motor data, if the motor type is not listed in the motor database)
 - feedback unit built into the motor (type, poles/lines/protocol)
 - · moment of inertia of the load

9.2.1.2 Minimum wiring for servo drive test without load, example

NOTICE

This wiring diagram based on default settings is for general illustration only and does not fulfill any requirements for EMC, functional safety, or functionality of your application.




9.2.1.3 Confirm connections (example: directly to PC)

You can turn on logic power to the servo drive through the X10 connector (mains power voltage is not needed for communications).



Confirm that the link LEDs on the servo drive (green LED on the RJ45 connector) and on your PC are both illuminated. If both LEDs are illuminated, then you have a working electrical connection.

Use WorkBench to configure the servo drive by using the service interface.



9.2.1.4 Industrial Ethernet Setup

Before connecting the servo drive to a PLC

- 1. Select the desired Industrial Ethernet type through the WorkBench software.
- 2. Follow the instructions in this manual to install WorkBench and connect to the servo drive.
- 3. Select the desired protocol in Express Setup or in the Industrial Ethernet view in Full Setup.

After selecting the protocol, set the device address.

PROFINET

Set the station name and IP address manually through the PROFINET master.

EtherNet/IP

Set the IP address for EtherNet/IP from the Industrial Ethernet view in WorkBench.

EtherCAT

The EtherCAT node is assigned automatically by the EtherCAT master. In order for WorkBench to connect to the drive over EtherCAT, TwinCAT/EoE must be utilized.

9.2.1.5 Install and start WorkBench

WorkBench is available on the Kollmorgen website. Select the install file and follow the instructions given by the installer.

Once the installation is complete, click the WorkBench icon to start the program.

9.2.1.6 Setup the axis in WorkBench

Use the setup wizard and

- 1. Connect the axis
- 2. Setup the axis
- 3. Save the parameter set to the servo drive

Refer to the WorkBench Online Help for details.

9.2.1.7 Enable the axis (Hardware)

- 1. Switch on 24V to X10 using any of the (+) and (-) pins. This will power on the servo drive logic.
- 2. Switch on 24V to the STO inputs (A) and (B) on X10. This will allow the servo drive to be enabled.

NOTE

- The X10 (+) pins are all internally connected allowing logic power to be bussed across multiple servo drives. The same is true for X10 (-) pins
- If machine STO is not required at this point, the plug is setup to easily jumper 24V from (+) to (A) on the left side of the plug, and from (+) to (B) on the right side of the plug. This will allow the servo drive to be enabled. For use in a machine, the input voltage to (A) and (B) is provided by the machine safety circuit.

9.2.1.8 Move the motor axis


- 1. Select the Axis in WorkBench
- 2. Under Motion, select Service Motion
- 3. Select **Reversing**, check the default velocity and time settings for plausibility
- 4. Select Start.

9.2.1.9 Tune the axis

Details see WorkBench Online Help

9.2.2 WorkBench Installation

This chapter describes the installation of the WorkBench software for the Kollmorgen Essentials Drive. Kollmorgen offers training and familiarization courses on request.



9.2.2.1 Use as directed

With the software to set up your drive you can alter and save the operating parameters for the Kollmorgen Essentials Drive series. The attached drive can be set up with the help of this software. During this procedure the drive can be controlled directly by the service functions.

Only professional personnel who have the relevant expertise (→ # 15) are permitted to carry out online parameter setting for a drive that is running.

Sets of data that have been stored on data media are not safe against unintended alteration by other persons. The use of unchecked data can result in unexpected movement. After loading a set of data always validate parameters which are relevant for the application before enabling the drive.

9.2.2.2 Software description

Each servo drive must be configured according to the requirements of your machine. For most applications you can use a PC and WorkBench (the software to setup your servo drive) to set up the operating conditions and parameters for your device.

An Ethernet cable connects the PC with the servo drive (→ #84), WorkBench establishes the communication between PC and servo drive.

Please find the software to set up your servo drive in the download area of the Kollmorgen website.

With WorkBench you can

- easily change parameters and directly see what happens with your drive due to a continuous online connection to the drive.
- read important and actual values from the drive which are displayed on the PC (oscilloscope functions),
- · save data sets on data media (archiving) and load them onto other drives or use them for backup and
- · print data sets.

Most standard feedback systems are plug and play compatible. Motor nameplate data is stored in the feedback device and read by the servo drive automatically at startup. Non-plug and play Kollmorgen motors are stored in WorkBench and can be loaded with one-click using the Motor screen in the software.

An extensive online help with integrated description of all variables and functions supports you in each situation.

9.2.2.3 Hardware requirements

The Service Interface X20 provides USB connection to a PC running WorkBench software for configuration, firmware updates and diagnostics.

Minimum requirements for the PC:

Processor: at least 1 GHz

RAM: 2 GB

Graphics adapter: Windows compatible, color, minimum 1024 x 768 dpi

Drives: hard disk with at least 500 MB free space Interface: one free Ethernet Interface or Switch port

9.2.2.4 Operating systems

Windows 7/8/10/11

- · WorkBench works with Windows 7, 8, 10 and 11
- Net framework 4.8.1 or higher is required
- Visual C++ Redistributable (2010, 2013, 2015)
- · Internet Explorer 10 or higher

Unix, Linux

The software does not run on Unix/Linux.

9.2.2.5 Installation under Windows 7/8/10/11


Use WorkBench to setup your servo drive. You can download the latest version from the Kollmorgen website.

Install the WorkBench as follows:

- 1. Download one of the following installation packages from www.kollmorgen.com:
 - Standard installation: Contains the application with complete help files. Dependencies like for example the .NET Framework will be downloaded from the internet if not already installed.
 - Full installation: Contains the application with complete help files and embedded dependencies like for example the .NET Framework.
- 2. After complete download, double-click on the downloaded file and follow the instructions.

Ethernet interface connection

Connect the interface cable to an Ethernet interface on your PC and to the service interface X20 (→ #84).



9.3 Switch-On and Switch-Off Behavior

This chapter describes the switch-on and switch-off behavior of the Kollmorgen Essentials Drive with STO.

Behavior of "holding brake" function

Servo drives with an enabled holding brake function have a special timing for switching on and off the output stage (\rightarrow #76). Events that remove the AXIS#.ACTIVE signal trigger the holding brake to apply. As with all electronic circuits, the general rule applies that there is a possibility of the internal holding brake module failing.

If the servo drive detects the motor to be at zero velocity (as configured by AXIS#.ZEROT and AXIS#.ZEROV) or timeout occurs during a stop procedure, the brake is applied. Set parameter AXIS#.MOTOR.BRAKEIMM to 1 with vertical axes, to apply the motor holding brake (→ # 76) immediately after faults or Hardware Disable.


Behavior when undervoltage condition is present

The behavior in an undervoltage condition depends on the VBUS.UVMODE setting.

VBUS.UVMODE	DC Bus Undervoltage Mode. Consult the WorkBench Online Help for configuring the parameter.
0	The servo drive will report a F2007 undervoltage fault any time an undervoltage condition occurs.
1 (default)	The servo drive will report a warning W2007 if not enabled. The servo drive will report a fault if it is enabled when the condition occurs, or an attempt is made to enable while an under voltage condition occurs.

9.3.1 Switch-on Behavior in Standard Operation

The diagram below illustrates the correct functional sequence for switching the drive on.



9.3.2 Switch-off Behavior


NOTE

The 24V supply of the servo drive must remain constant. STO disables the power stage immediately. Configured digital inputs and Industrial Ethernet commands can be used to perform controlled stops.

9.3.2.1 Switch-off behavior using the AXIS#.DIS command

The enable/disable button in WorkBench issues a *AXIS#.DIS* command internally to the drive. See *WorkBench Online Help* for configuring inputs and software commands. Sometimes this enable signal is called "Software Enable" (SW-Enable).

AXIS#. DISMODE	AXIS#.DISMODE controls the behavior of the AXIS#.DIS command issued through WorkBench, or terminal, or fieldbus.
0	Disable axis immediately, if the servo drive detects the motor to be at zero velocity AXIS#.ZEROV or timeout occurs brake is applied. Category 0 stop according to IEC 60204 (→ # 21).
2	Use controlled stop to disable servo drive, if the servo drive detects the motor to be at zero velocity <i>AXIS#.ZEROV</i> or timeout occurs brake is applied. Category 1 stop according to IEC 60204 (→ # 21).




If the servo drive detects the motor to be at zero velocity (AXIS#.ZEROV) or timeout occurs (AXIS#.ZEROT), the motor brake is applied $(\rightarrow #76)$.

9.3.2.2 Switch-off behavior using a digital input (controlled stop)

This is a category 1 stop according to IEC 60204 (→ #21).

A digital input can be configured to bring the servo motor to a controlled stop and then disable the servo drive and apply the holding brake (if present). See the *WorkBench Online Help* for information on configuring Digital Inputs.




If the servo drive detects the motor to be at zero velocity (AXIS#.ZEROV) or timeout occurs (AXIS#.ZEROT), the motor brake is applied $(\rightarrow #76)$.

9.3.2.3 Switch-off behavior using STO input (uncontrolled stop)

This is a category 0 stop according to IEC 60204 (→ #21).

The STO input disables the power stage immediately.




If the servo drive detects the servo motor to be at zero velocity (AXIS#.ZEROV) or timeout occurs (AXIS#.ZEROT), the servo motor brake is applied (\rightarrow # 76). Set parameter AXIS#.MOTOR. BRAKEIMM to 1 with vertical axes, to apply the motor holding brake immediately after STO.

9.3.2.4 Switch-off behavior in the event of a fault

The behavior of the servo drive always depends on the fault type and the setting of a number of different parameters (AXIS#.DISMODE, VBUS.UVFTHRESH, AXIS#.ZEROV, and others; see the *WorkBench Online Help* for more details). See the *Drive Fault and Warning Messages and Remedies* section of the *WorkBench User Manual* for a table describing the specific behavior of each fault. The next pages show examples for the possible fault behaviors. The fault relay output (DOUT9) switches the main contactor (Emergency Off circuit).

Switch-off behavior for faults that cause an immediate power stage disable


This is a category 0 stop according to IEC 60204 (→ #21).



If the servo drive detects the servo motor to be at zero velocity (AXIS#.ZEROV) or timeout occurs (AXIS#.ZEROT), the motor brake is applied (\rightarrow # 76). Set parameter AXIS#.MOTOR. BRAKEIMM to 1 with vertical axes, to apply the motor holding brake immediately after faults.

Switch-off behavior for faults that cause dynamic braking


This is a category 2 stop according to IEC 60204 (→ #21).



If the servo drive detects the motor to be at zero velocity (AXIS#.ZEROV) or timeout occurs (AXIS#.ZEROT), the motor brake is applied (\rightarrow #76).

Switch-off behavior for faults that cause a controlled stop

This is a category 2 stop according to IEC 60204 (→ #21).



If the servo drive detects the motor to be at zero velocity (AXIS#.ZEROV) or timeout occurs (AXIS#.ZEROT), the motor brake is applied (\rightarrow # 76).

9.4 Fault and Warning Messages

Definition

A fault is generally a notification of a critical system failure which will stop machine operation. Depending on the severity of the fault will depend on which system-stop mechanism is used.

A warning is generally a notification to the user which is not critical and does not require the machine to immediately shut off.

Faults and Warnings follow the same pattern and are identified by a four digit code:

G G X X, where GG is a two digit group code, and XX is a two digit ID.

GG	Group	GG	Group
10	System	4#	Feedback (# indicates feedback number)
11	File	50	Motor
15	Hardware	55	Wake and Shake
20	Power	60	Motion
25	Temperature	70	Fieldbus
30	Software	90	Safety

The following ways will help you identify a system failure:

- 1. Visible inspection: See status LED on the front side of the servo drive (→ #40).
- 2. Via Fieldbus: Fault status will be reported to higher level PLC.
- 3. Via Service port: Connect the servo drive directly to your PC via USB and identify any errors with WorkBench.



Eliminate errors and faults in compliance with work safety rules. Troubleshooting only by qualified and trained staff.



More information about fault messages, remedy and clearing faults can be found in the WorkBench User Manual.

9.5 Troubleshooting

Servo drive problems occur for a variety of reasons, depending on the conditions in your installation. If you cannot resolve a fault or other issue using the troubleshooting guidance presented below, customer support can give you further assistance.



Eliminate errors and faults in compliance with work safety rules. Troubleshooting only by qualified and trained staff.



More details on the removal of faults can be found in the WorkBench User Manual.

Problem	Possible Causes	Remedy
HMI message: Communication fault	 wrong cable used, cable plugged into wrong position on servo drive or PC wrong PC interface selected 	 plug cable into the correct sockets on the servo drive and PC select correct interface
Drive does not enable	 HW Enable configured but not wired HW or SW Enable not set 	 connect HW Enable to the selected input Apply 24V to HW Enable and select SW Enable in WorkBench / Fieldbus
Motor does not rotate	 servo drive not enabled software enable not set break in setpoint cable servo motor phases swapped brake not released servo drive is mechanically blocked servo motor pole no. set incorrectly feedback set up incorrectly 	 apply ENABLE signal set software enable check setpoint cable correct servo motor phase sequence check brake control check mechanics set servo motor pole no. set up feedback correctly
Motor oscillates	 gain is too high (speed controller) feedback cable shielding broken AGND not wired up 	 reduce AXIS#.VL.KP (speed controller) replace feedback cable join AGND to CNC-GND
Drive reports following error	 Irms or Ipeak set too low current or velocity limits apply accel/decel ramp is too long 	 verify servo motor/drive sizing verify that AXIS#.IL.LIMITN/P, AXIS#.VL.LIMITN/P are not limiting the servo drive reduce AXIS#.ACC/AXIS#.DEC
Motor overheating	 servo motor operating above its rating servo motor current settings incorrect 	 verify servo motor/drive sizing verify servo motor continuous and peak current values are set correctly
Drive too soft	 AXIS#.VL.Kp (velocity) too low AXIS#.VL.Ki (velocity) too low filters set too high 	 increase AXIS#.VL.KP (velocity) increase AXIS#.VL.KI (velocity) refer to documentation regarding reducing filtering (AXIS#.VL.AR*)
Drive runs roughly	 AXIS#.VL.Kp (velocity) too high AXIS#.VL.Ki (velocity) too high filters set too low 	 reduce AXIS#.VL.KP (velocity) reduce AXIS#.VL.KI (velocity) refer to documentation regarding increasing filtering (AXIS#.VL.AR*)

10 Safety Manual for FS1

Revision History for Safety Manual

Revision	Remarks
S101, 09/2025	Functional Safety Option 1

The Safety Manual is valid for:

Kollmorgen Essentials Drive with Functional Safety Option 1 (FS1)

KED - xxx - xxxxx - x1xx - xxxx

Safety Functions: STO; SIL2 PLd, activation by digital I/O

Hardware Revision	Drive Firmware	WorkBench
AA	from 02-15-00-001	2.19.0.11848

Contents:

10.1	General Notes	106
10.2	Verification	111
10.3	Safety Function Option 1 (I/O, SIL2 PLd)	112
10.4	Safety Faults, Safety Warnings	118
	Functional Safety Parameter Reference	

10.1 General Notes

Resulting Functional Safety classification (SIL and/or PL level) is calculated across the drive system. The drive system usually consists of the following:

- motion controller (e.g. AKC/KAS),
- safety controller (e.g. SCU or similar),
- servo drives (e.g Kollmorgen Essentials Drive) and servo motors (e.g. Kollmorgen Essentials Motor),
- · motor brakes, feedback systems,
- cables to connect servo drive and motor,
- sensors/actors

The safety properties listed in this chapter can be reached with Kollmorgen components.

NOTICE

Ensure the compliance of the application with all relevant directives and local electrical code. You are responsible for implementation and validation of the drive system and safety system.

Only properly qualified personnel are permitted to perform installation, setup and verification/validation tasks.

- Mechanical installation: only by qualified personnel with mechanical expertise according to IEC 60417-6183.
- Electrical installation: only by qualified personnel with electrotechnical expertise according to IEC 60417-6182.
- Verification/Validation: only by trained personnel after any changes to the installation. The expertise of the personnel must be appropriate to the complexity and safety integrity level of the drive system.

NOTE

Safe State (= STO Active):

In a safe state the drive removes the motor torque from all axes.



CAUTION

High electrical voltage!

Risk of electrical shock! The safety functions do not provide an electrical separation from the power output. If manual access to the motor or drive power terminals is necessary,

- disconnect the drive from mains supply,
- consider the discharging time of the DC-Bus link,
- ensure the cabinet is safely disconnected and protected against unintended switch-on (for instance, with a lock-out and warning signs).



WARNING Ejection of molten particles!

If particles fall into the drive or the drive has been damaged, molten drive component particles may be ejected causing injuries. Shut down the drive and wear appropriate protective gear during maintenance work, troubleshooting and fault rectification. (→ #26)

10.1.1 Use as directed

Safety functions are intended to reduce the risk of the machine operation to the required tolerable risk. To achieve functional safety, the wiring of the safety circuits must meet the safety requirements of IEC 60204, ISO 12100 and ISO 13849.

NOTICE

- The network the drive is connected to must be secured according to state-of-the-art information technology security requirements.
- The IT specialists shall analyze whether further security requirements are applicable to ensure functional safety.
- The drive firmware can be updated. The parameter sets must be reloaded, verified and proof tested before normal operation is started.
- In certain types of machinery, two motors drive a single mechanical axis. It is the
 responsibility of the user to ensure that a fault reaction on the first motor-drive set is also
 carried out on the second motor-drive set and vice versa. Safe I/O and/or a safe fieldbus
 such as FSoE can be used to achieve this.

10.1.2 Prohibited use

The safety functions must not be used if the drive is to be made inactive for Emergency-Off situations. In an Emergency-Off situation, the main relay is switched off by the Emergency-Off button.

The STO function requires two-channel control if the performance level SIL2 / PLd Cat.3 in the system is to be achieved. The connection of a constant 24 VDC voltage to one of the STO inputs is not permitted if the safety function is to be used.

Never modify the drive!



Never open the cover of the drive, as the electronic components installed there generate dangerous high voltages. Even after disconnection from the mains, the components often still carry high voltage.

Therefore, the drive may only be opened by authorized specialist personnel.

Kollmorgen shall not be held accountable for any defects, malfunctions or degradations resulting from users opening up the device. In case of damage or malfunction, send the drive for repair or replacement.

10.1.3 Abbreviations used for functional safety

More abbreviations see (→ # 12).

Abbreviation	Meaning	
A#, AXIS#	A# or AXIS# are used for axis 1, with parameters (AXIS#.SAFE.STO.ACTIVE) or signal names (STO-A-A#)	
(→ # 53)	"see page 53" in this document	
→ xyz	"see chapter xyz" in this document	
CCF	Common Cause Failure	
FS1	Functional Safety Option 1 (STO)	
HFT	Hardware Fault Tolerance	
MTTFd	Mean time to dangerous failure	
OSSD	Output Switching Signal Device	
PELV	Protective Extra Low Voltage	
PFH	Probability of dangerous failure per hour	
PL	Performance Level	
SC	Systematic Capability	
SFF	Safe Failure Fraction	
SIL	Safety Integrity Level	
STO	Safe Torque Off	
TM	Mission Time	

10.1.4 Enclosure, wiring

Enclosure

Since the servo drive meets IP20, you must select an enclosure that permits safe operation of the servo drive. The enclosure must at least meet IP54 \cdot

Transport in accordance with IEC 61800-2						
NOTE	Fransport only in the manufacturer's original recyclable packaging.					
Temperature	25 to +70 °C, maximum rate of change 20 K/hour, class 2K3.					
Relative Humidity	max. 95% at +40 °C, no condensation, class 2K3.					
Shock	NOTICE: Avoid shocks while transporting. Drive modules are tested for environmental class 2M1 of IEC 60721-3-2.					

Storage in accordance with IEC 61800-2 Temperature -25 to +55 °C, maximum rate of change 20 K/hour, class 1K4.				

Operation in accordance with IEC 61800-2					
Environmental Class	Environmental class 3K3				
	0 to +40 °C under rated conditions				
	 +40 to +60 °C with current derating 3 % per Kelvin 				
Temperature	External regen resistor used:				
	0 to +40 °C under rated conditions				
	• +40 to +55 °C with current derating 3% per Kelvin				
Relative Humidity	5 to 85%, no condensation, IEC 61800-2 class 3K3				
	Up to 1000 m above mean sea level (AMSL): no restriction				
Site Altitude	• 1,000 to 2,000 m AMSL: power derating 1.5%/100 m				
	Maximum altitude: 2000 m AMSL				
Drive EMC Immunity	Increased immunity according to EN 61800-5-2				
Drive Pollution Level	Pollution level 2 as per IEC 60664-1				
Drive Vibration Class	Class 3M1 according to IEC 61800-2				
Drive Shock Class	Class L according to IEC 61800-2				
Drive Protection Class	IP20 according to IEC 60529				
Enclosure	Minimum cabinet size (WxHxD): 406 x 406 x 254 mm				
Enclosure Protection	At least IP 54 according to IEC 60529				

Wiring

Wiring inside the specified enclosure (IP54) must meet the requirements of the standard IEC 60204-1 and ISO 13849-2 (Table D.4). Use copper wires, 0.5mm² (20 awg), wire ferrules. Maximum distance for unshielded I/O lines is 3m inside the cabinet. If the I/O cable leaves the cabinet, it must be EMC shielded.

Wiring outside the specified enclosure must be laid durably protected from outside damage (for example, by laying the cable in a duct, placed in different sheathed cables, or protected individually by grounding connection).



When wiring the digital inputs and outputs, avoid short circuits between the inputs, outputs, or to supply lines.

10.2 Verification

Check and verify the STO wiring (examples (→ # 114)). The installation must be verified by trained personnel after any changes to the installation. The expertise of the personnel must be appropriate to the complexity and safety integrity level of the drive system.

Diagnostic test



Test the STO function after initial start of the axis, after each intervention into the wiring of the system, or after exchange of one or several components of the drive system. The proof test interval is one year to meet the required PFH.

Precondition: <u>AXIS#.SAFE.STO.REPORTFAULT</u> = 1 **Warning:** Do not enter hazardous area during proof test!

Method 1, axis remains enabled			hod 2, axis disabled
1.	Stop the axis to standstill.	1.	Stop the axis to standstill.
2.	2. Caution: Block vertical load.		Caution: Block vertical load.
3.	Keep the axis enabled.	3.	Disable the axis.
4.	Activate the STO function for example by opening the protective screen.	4.	Activate the STO function, for example, by opening the protective screen
5.	The axis displays fault F9000.	5.	The axis displays fault W9000.

10.3 Safety Function Option 1 (I/O, SIL2 PLd)

The safety function STO on the Kollmorgen Essentials Drive with functional safety option 1 is certified.

NOTICE

The servo drive is ready to operate with pre-configured STO function.

Standards

Standard	Content		
ISO 13849- Safety of machinery: Safety-related parts of control systems			
1:2023			
IEC 62061:2021	Functional safety of electrical/electronic/programmable electronic safety-related systems		

Available Safety Functions

Abbr.	br. Function Activation		Refer to		
STO	Safe Torque Off	Safe digital inputs	(→ # 114)		

10.3.1 Safety Properties Overview

OSSD test pulses are not required. The inputs however are compatible with safety equipment that emits test pulses. Incoming test pulses of up to 1ms duration are ignored. The dwell time of the test pulses should not exceed 10%.

The hardware fault tolerance is HFT = 1 according to IEC 61508. Two faults might lead to loss of the safety functions.

The systematic capability according to IEC 61508 for the safety-related subsystems of the drive are SC = 2. TM = 20 Years, SFF = 75%.

Function	ISO 13849-1	MTTF _d Years		IEC 62061	PFH [1/h]	CCF [%]	Response Time
STO dual channel	PL d, Cat. 3	100	71.5	SIL2	1.0E-09	65	< 10ms

NOTE

Execute the STO function at least once per year to achieve SIL2.

10.3.2 Technical Data

NOTE

Safe inputs are fixed to the STO function.

When the STO function (Safe Torque Off) is not needed, then all STO inputs must be connected directly with +24V. The STO function is then bypassed and cannot be used.

I/O hardware data

- Reference ground is DGND
- Galvanic isolation for 60 VDC
- Activation delay about 5 µs
- De-activation delay about 500 µs
- Use 24 VDC ±15% PELV power supply
- High level 17 VDC to 30VDC, 5mA to 6mA
- Low level 0 VDC to 5 VDC, max.1mA

Pinout

	X10	Signal	Description		
	4A	STO-A	STO channel A		
4B STO-B		STO-B	STO channel B		

Parameters

Parameter	Description
AXIS#.SAFE.STO.A	Reads the status of STO input channel A.
AXIS#.SAFE.STO.B	Reads the status of STO input channel B.
AXIS#.SAFE.STO.ACTIVE	Reads the STO status.
AXIS#.SAFE.STO.REPORTFAULT	F9000 and W9000 are triggered, if set to 1 (default).

NOTE

For parameter description refer to the *Safety Parameters Reference Guide*(→ # 120).

Factory Default Settings

- The servo drive is ready to operate with pre-configured STO function.
- AXIS#.SAFE.STO.REPORTFAULT is set to 1.

10.3.3 STO (Safe Torque Off)

Safe Torque Off description for drive option Functional Safety 1.

STO is suited for SIL 2 according to IEC 62061 and PLd / Cat.3 according to ISO 13849-1. It is a type A subsystem according to IEC 61508.

This safety function turns off the drive output stage that powers the motor and corresponds to an uncontrolled stop according to IEC 60204-1, category 0.

10.3.3.1 Important Notes

NOTICE

The safety properties given in this documentation refer to the device Kollmorgen Essentials Drive with functional safety option 1. You need to determine the safety properties of the safety chain.



WARNING Vertical load could fall!

Serious injury could result when a suspended load is not properly blocked. The drive cannot hold a vertical load when STO is active.

Add a safe mechanical blocking (for instance, a motor-holding brake).

10.3.3.2 Activation

The digital STO inputs (channel A and B) must be connected to the output of a safety device, which at least meets the requirements of PLd, Cat. 3 according to ISO 13849. Technical data of the safe inputs (→ # 112).

If one of the STO inputs goes open-circuit or 0V, then power supply to the servo motor stops within <10ms. The servo motor will lose all torque and coast to a stop.


If the servo drive detects that the two STO inputs are in a different state for longer than 100ms, then a simultaneity fault F9005 occurs (→ # 117).

NOTE

Review the enclosure and wiring instructions (\rightarrow # 109).

Wiring example STO, SIL2/PLd, Emergency Stop


Note: Set AXIS#.SAFE.STO.REPORTFAULT to 1 if STO is activated by a switch.




10.3.3.3 Restart

Examples

	AXIS#.SAFE.STO. REPORTFAULT = 1	AXIS#.SAFE.STO. REPORTFAULT = 0
Example 1:	Message W9000	Restart:
Axis was disabled, STO is activated	Restart:	1. deactivate STO
	1. deactivate STO	2. enable axis
	2. enable axis	
Example 2:	Messages W9000 and F9000	Restart:
Axis was enabled, STO is activated	Restart:	1. deactivate STO
	1. disable axis	
	2. deactivate STO	
	3. clear fault	
	4. enable axis	
Example 3:	Message F9005	Message F9005
Axis was disabled, STO is activated	Restart:	Restart:
faulty	1. check wiring	1. check wiring
	2. remedy the cause	2. remedy the cause
	3. deactivate STO	3. deactivate STO
	4. clear fault	4. clear fault
	5. enable axis	5. enable axis






Timing	max	Remarks		
t1		STO channel A enabled (0 V)		
t1 to t2	<10ms	STO enable delay (response time)		
t2		STO active		
t3		STO channel B enabled (0 V)		
t1 to t3	≤100ms	accepted delay between dual channel edges		
t4		STO channel B disabled (+24 V)		
t5		STO channel A disabled (+24 V)		
t4 to t5	≤100ms	accepted delay between dual channel edges		
t5 to t6	<10ms	STO release delay		
t6		STO release		
t6 to t7		Zero if <u>AXIS#.SAFE.STO.REPORTFAULT</u> =0 Until 'no fault' if <u>AXIS#.SAFE.STO.REPORTFAULT</u> =1		
t7		Power stage enabled.		

10.3.3.5 Safety Diagnostic view in WorkBench

The WorkBench view "Safety Diagnostic" shows the current status on the safe inputs ($\underline{AXIS\#.SAFE.STO.A}$ / $\underline{AXIS\#.SAFE.STO.B}$) and the logical status of the STO function for the axis.



10.3.3.6 Fault Reaction / Failure Messages

With the dual-channel control of the STO (SIL2/PLd Cat.3) safety function, the switch-off paths STO-A-A# and STO-B-A# are switched separately by two outputs of a safety controller.

W9000 and F9000 are conditioned by the value of AXIS#.SAFE.STO.REPORTFAULT.

AXIS#.SAFE.STO.REPORTFAULT set to 1 (default)

STO-A-A#	STO-B-A#	ENABLE	Drive Message	Motor Torque	Safe State
0 V	0 V	0 V	W9000	No	Yes
0 V	0 V	+24 V	F9000	No	Yes
+24 V	+24 V	0 V	-	No	No
+24 V	+24 V	+24 V	-	Yes	No
+24 V	0 V	0 V	F9005*	No	Yes
+24 V	0 V	+24 V	F9005*	No	Yes
0 V	+24 V	0 V	F9005*	No	Yes
0 V	+24 V	+24 V	F9005*	No	Yes

^{*} different status of STO-A/B for more than 100ms A#: A1 for axis 1.

AXIS#.SAFE.STO.REPORTFAULT set to 0

STO-A-A#	STO-B-A#	ENABLE	Drive Message	Motor Torque	Safe State
0 V	0 V	0 V	W9000	No	Yes
0 V	0 V	+24 V	W9000	No	Yes
+24 V	+24 V	0 V	-	No	No
+24 V	+24 V	+24 V	-	Yes	No
+24 V	0 V	0 V	F9005*	No	Yes
+24 V	0 V	+24 V	F9005*	No	Yes
0 V	+24 V	0 V	F9005*	No	Yes
0 V	+24 V	+24 V	F9005*	No	Yes

^{*} different status of STO-A/B for more than 100ms A#: A1 for axis 1.

10.4 Safety Faults, Safety Warnings

The Kollmorgen Essentials Drive with safety option 1 does not have safety failure modes.

10.4.1 Drive Safety Faults

NOTE

More information about servo drive fault messages, remedy and clearing faults can be found in the WorkBench User Manual.

Fault	Description	Cause	Remedy
F9000	Safe Torque Off	STO function has been triggered while the axis was enabled.	See (→ # 1, STO (Safe Torque Off))
F9004	Safe Torque Off digital and analog lines don't match	Hardware fault on the power board.	Restart drive. If issue persists, contact technical support.
F9005	STO Simultaneity	The two STO inputs did not change state within 100ms of each other.	Check wiring and safety apparatus

10.4.2 Safety Warnings

NOTE

More information about servo drive warnings can be found in the WorkBench User Manual.

Warning	Description	Cause	Remedy
W9000	Safe Torque Off	STO function has been triggered.	See (F9000, → #118)

10.4.3 Troubleshooting Functional Safety

NOTICE

Eliminate errors and faults in compliance with work safety rules. Troubleshooting must only be performed by qualified and trained staff.

Problem	Possible Causes	Remedy causes		
A group "90" safety fault or safety warning message is visible in WorkBench	Refer to the Drive Safety Fault and V	Warning tables (→ # 118).		
A fault or warning message of another group than "90" is visible WorkBench	Refer to the drive fault and drive warnings tables (→ # 102) and more detailed descriptions in the WorkBench User Manual.			
Safety faults and warnings are not visible/reported	AXIS#.SAFE.STO. REPORTFAULT is set to 0	Set AXIS#.SAFE.STO. REPORTFAULT to 1		
STO cannot be deactivated (no torque)	 External safety device defective. STO wiring defective. Auxiliary voltage low. STO inputs defective. F9004 visible F9005 visible. OSSD pulses too long (>1ms). STO channels are unequal for more than 100ms. 	 Check external safety device. Check STO wiring for short-circuit or similar. Check voltage level (→ # 112). Send drive to manufacturer for repair. Send drive to manufacturer for repair. Check safety hardware system. Check safety controller. Switch off OSSD. Check external safety device. 		
Drive does not enable	1. STO is still active.	1. Deactivate STO prior to HW Enable.		

10.5 Functional Safety Parameter Reference

Abbreviations

- Acc. = Access: RO = Read Only, RW = Read/Write, WO = Write Only
- N/A = Not Available, Y = Yes, N = No
- · Parameters are sorted alphanumerically

Parameters related to safety functions	Acc.	Default	Parameter	CAN ove	CAN over EtherCAT	
			Package	Axis Index 0x	Sub	
AXIS#.SAFE.STO.A	RO	N/A	N/A	5007	3	
AXIS#.SAFE.STO.ACTIVE	RO	N/A	N/A	5007	2	
AXIS#.SAFE.STO.B	RO	N/A	N/A	5007	4	
AXIS#.SAFE.STO.REPORTFAULT	RW	1	Servo Drive	5007	1	

10.5.1 Safety Parameters, sorted alphanumeric

10.5.1.1 AXIS#.SAFE.STO.A

Description

Indicates the state for STO-A input.

Value	Description		
1	24V present (STO inactive, allowed to enable)		
0	24V not present (STO active, axis disabled)		

Context

For complete STO information refer to "STO (Safe Torque Off)" (\rightarrow # 114).

Versions

Action	Version	Notes
Implemented	02-00-00-000	

General Information

Туре	Read Only
Units	N/A
Range	0 or 1
Default Value	N/A
Data Type	Integer
Stored in Non-Volatile Memory	No

EtherCAT CoE and CANopen

Command	Index	SubIndex	Data Type	Units	Float Scale	Access	PDO Mappable
AXIS1.SAFE.STO.A	5007h	03h	Unsigned8	-	-	Read only	Yes

EtherNet/IP

ID	Instance	Attribute	Name	Data Type	Access	User Mappable
10000	1	10000 (0x2710)	AXIS1.SAFE.STO.A	Unsigned8	Read Only	Yes

Parameter	PNU	Data Type	Access	Units
AXIS1.SAFE.STO.A	10000	Unsigned8	Read Only	-

10.5.1.2 AXIS#.SAFE.STO.B

Description

Indicates the state for STO-B input.

Value	Description			
1	24V present (STO inactive, allowed to enable)			
0	24V not present (STO active, axis disabled)			

Context

For complete STO information refer to "STO (Safe Torque Off)" (\rightarrow # 114).

Versions

Action	Version	Notes
Implemented	02-00-00-000	

General Information

Туре	Read Only
Units	N/A
Range	0 or 1
Default Value	N/A
Data Type	Integer
Stored in Non-Volatile Memory	No

EtherCAT CoE and CANopen

Command	Index	SubIndex	Data Type	Units	Float Scale	Access	PDO Mappable
AXIS1.SAFE.STO.B	5007h	04h	Unsigned8	-	-	Read only	Yes

EtherNet/IP

ID	Instance	Attribute	Name	Data Type	Access	User Mappable
10001	1	10001 (0x2711)	AXIS1.SAFE.STO.B	Unsigned8	Read Only	Yes

Parameter	PNU	Data Type	Access	Units
AXIS1.SAFE.STO.B	10001	Unsigned8	Read Only	-

10.5.1.3 AXIS#.SAFE.STO.ACTIVE

Description

Indicates the Safe Torque Off (STO) state of the axis.

Value Description	
1	STO active (inputs +0V)
0	STO inactive (inputs 24V)

Context

For complete STO information refer to "STO (Safe Torque Off)" (→ # 114).

Versions

Action	Version	Notes
Implemented	02-00-00-000	

General Information

Туре	Read Only
Units	N/A
Range	0 or 1
Default Value	N/A
Data Type	Integer
Stored in Non-Volatile Memory	No

EtherCAT CoE and CANopen

Command	Index	SubIndex	Data Type	Units	Float Scale	Access	PDO Mappable
AXIS1.SAFE.STO.ACTIVE	5007h	02h	Unsigned8	-	-	Read only	Yes

EtherNet/IP

ID	Instance	Attribute	Name	Data Type	Access	User Mappable
10002	1	10002 (0x2712)	AXIS1.SAFE.STO.ACTIVE	Unsigned8	Read Only	Yes

Parameter	PNU	Data Type	Access	Units
AXIS1.SAFE.STO.ACTIVE	10002	Unsigned8	Read Only	-

10.5.1.4 AXIS#.SAFE.STO.REPORTFAULT

Description

This parameter controls whether a Safe Torque Off (STO) fault F9000 will be created when STO is activated while the axis is enabled. The STO warning W9000 is always generated if this parameter is 1 and the STO function is active.

Value	Description
1	W9000 / F9000 are generated when axis is enabled and an STO occurs (default)
0	W9000 / F9000 are not generated

Context

For complete STO information refer to "STO (Safe Torque Off)" (→ # 114).

Versions

Action	Version	Notes
Implemented	02-00-00-000	

General Information

Туре	Read/Write
Units	N/A
Range	0 or 1
Default Value	1
Data Type	Integer
Stored in Non-Volatile Memory	Yes

EtherCAT CoE and CANopen

Command	Index	SubIndex	Data Type	Units	Float Scale	Access	PDO Mappable
AXIS1.SAFE.STO.REPORTFAULT	5007h	01h	Unsigned8	-	-	Read/Write	No

EtherNet/IP

ID	Instance	Attribute	Name	Data Type	Access	User Mappable
10003	1	10003 (0x2713)	AXIS1.SAFE.STO.REPORTFAULT	Unsigned8	Read/Write	Yes

Parameter	PNU	Data Type	Access	Units
AXIS1.SAFE.STO.REPORTFAULT	10003	Unsigned8	Read/Write	-

11 Essentials Cables

Kollmorgen can only guarantee the performance and quality of its servo systems when you use servo motors, servo drives and cables supplied by Kollmorgen. Not all cables are created equal.

The Kollmorgen Essentials Cable not only works with Kollmorgen Essentials Motors, but will also work with Kollmorgen AKM and AKM2G servo motors configured with a "9" connector option for AKM or "A" connector option for AKM2G and SFD-M or SFD-3 feedback.

11.1 Essentials Cable Properties

Bend Radius and Weight Specifications

	Main	0.0	Bend Rad	lius (min.)	Cable	Weight
Cable Type	Conductor Size [mm²]	Conductor Size [mm]	Static [mm]	Dynamic [mm]	Assembled Weight of 1 Meter Cable [kg]	Weight Adder per Meter [kg/m]
	1.5	13.2	66	92.4	0.40	0.20
H2	2.5	14.2	71	99.4	0.55	0.25

Note: Essentials Cables are rated for 80°C and 1000V

Life Cycle - Lifetime at Specified Conditions

Cable Type	Cycles @ Bend Radius [F x DIA]	Temp from/to [°C]
H2	12E+06	-40/+90


Certifications/Standards

CE Oil Resistance
CEI 20-35 Flame Resistance
Lead-free Silicone-Free
Clean room UL/ULC
NFPA 79

Kollmorgen Essentials Hybrid Cable Wiring Specifications

Cable	Туре	Cross Section [mm²]	Current Carrying Capacity	Remarks
H2-51-015-A5-xxxx00	Power + Brake + SFD-M / SFD3 /	(4x1.5+(2x0.34)+(2x0.75))	10.1A < 10rms ≤ 13.1A	1000 V rated, 80°C Current carrying capacity acc. to IEC 60204-1:2006 Table 6, Column B2
H2-51-025-A5-xxxx00	HDSL	(4x2.5+(2x0.34)+(2x1.0))	13.1A < 10rms ≤ 17.4A	4 power lines & 2 brake lines & 2 SFD-M/SFD3/DSL signal lines

11.2 Essentials Cable Nomenclature



Kollmorgen Essentials Cable Options

- H2-51-015-A5-xxxx00 for KED-SPM-6V03S, KED-SPM-6V06S
- H2-52-025-A5-xxxx00 for KED-SPM-6V12S, KED-SPM-7VxxS


Each cable option will have 25 SKUs, from 001000 (1 m) up to 025000 (25 m)

11.3 Essentials Cable Connector Pinouts

A5

Drive Connector X1: Motor, Power + Brake

Signal	Description
BR-	Motor holding brake
BR+	Motor holding brake
PE	Protective Earth (motor housing)
U	Motor Phase U
V	Motor Phase V
W	Motor Phase W






Drive Connector X23: Feedback Pinouts

Pin	SFD-M
1	COM+
2	COM-





12 Accessories for Kollmorgen Essentials Drives

Contact an authorized Kollmorgen Essentials distributor or Kollmorgen Customer Support to place an order, or to request more information.


Regen Resistors - External IP40

BAFP(U)-85-33-S 85 W, 33 Ohm, 210 x 60 x 27 mm

For use with 6V03 and 6V06 drives

BAFP(U)-100-33-S 100 W, 33 Ohm, 239 x 70 x 27 mm

For use with 6V12 and 7Vxx drives



EMC Filters

	Filter Order Code				
	≤ 10 m Standard EMC		> 10 m Cable High EMC Requiremen		
Drive Model	1 phase	3 phase	1 phase	3 phase	
6V03	KED-1MF-06	KED ONE 40	DE-202203	DE 20220E	
6V06	KED-1MF-10	KED-3MF-10	DE-202204	DE-202205	
6V12	KED-1MF-20	KED-3MF-20	DE-TBD	DE-202206	



Chokes Motor Chokes are not needed for 6Vxx drive models

Mating Connectors

KED-CONKIT-MV36 Connector kit with X3 and X10 connectors for

6V03S, 6V06S

KED-CONKIT-MV12 Connector kit with X3 and X10 connectors for 6V12S

KED-CONKIT-HV Connector kit with X3 and X10 connectors for 7VxxS

KED-CON-X3-MV36 Mating connector X3 (Mains Power) for 6V03S,

6V06S

KED-CON-X3-MV12 Mating connector X3 (Mains Power) for 6V12

KED-CON-X3-HV Mating connector X3 (Mains Power) for 7Vxx

KED-CON-X10 Mating connector X10 (24V in and STO)



Shield Clamp

KED-SHIELD-25

Shield clamp for up to 2.5mm² cable



13 Certificates and Declarations

NOTICE

If the servo drive is labeled Beta, approvals are pending.

12 1	Conformance with UL/cUL & CSA	130
10.1	Colliditiance with object a CSA	130
	Conformance with EU	
13.3	Conformance with PFAS	132
13.4	Conformance with CAL_Prop65	133
13.5	Conformance with POP	133
13.6	Conformance with TSCA	133
13.7	Conformance with EtherCAT	133

13.1 Conformance with UL/cUL & CSA

13.1.1 3-12 A drives

This servo drive is listed under UL (Underwriters Laboratories Inc.) file number E141084.

USL, CNL - Power conversion equipment (NMMS, NMMS7)

USL (United States Standards - Listed): Indicates Investigated to United States Standard for Power Conversion Equipment, UL 61800-5-1.

CNL (Canadian National Standards - Listed): Indicates investigation to Canadian Standard for Industrial Control Equipment, CAN/CSA - C22.2, No. 274-17.

UL Markings / Marquages UL

English	Français
Integral solid state short circuit protection does not provide branch circuit protection. Branch circuit protection must be provided in accordance with the National Electrical Code, Canadian Electrical Code, or Machinery Directive, and any additional local codes.	Une protection de court-circuit à semi- conducteur intégrale ne fournit pas de protection de la dérivation. Il convient de garantir une protection de la dérivation conforme au NEC et aux réglementations locales en vigueur.
 This product is suitable for use on a circuit capable of delivering not more than 5 kA (SCCR) when protected by class J fuses. 	 Ce produit peut être utilisé sur un circuit capable de délivrer un maximum de 5 kA (SCCR) lorsqu'il est protégé par des fusibles ou des disjoncteurs de classe J.
 Suitable for motor group installation on a circuit capable of delivering not more than 5 kA (SCCR) symmetrical. 	 Convient pour une installation de groupe moteur sur un circuit capable de délivrer pas plus de 5 kA rms symétriques.
 These drives provide Class 10 solid state motor overload protection at 120% of the rated FLA current. The drive overload trip point should not be set to less than 10% above the motor rated current: AXIS#.IL.FOLDFTHRESHU ≥ 1.1 * AXIS#.MOTOR.ICONT. 	 Ces variateurs offrent une Class 10 protection contre les surcharges de moteur à semi- conducteur à 120% du courant FLA nominal. Le point de déclenchement en surcharge du variateur ne doit pas être réglé à moins de 10% au dessus du courant nominal du moteur: AXIS#.IL.FOLDFTHRESHU ≥ 1,1 * AXIS#.MOTOR.ICONT.
 These devices are intended to be used in a pollution degree 2 environment and must be placed in an enclosure with min. size of 16 x 16 x 10 inches 	 Ces appareils sont prévus pour une utilisation dans un environnement de pollution de niveau 2 et doivent être placés dans une enceinte avec min. taille de 406 x 406 x 254 mm
• Surrounding air temperature 40°C. Refer to chapter "Ambient Conditions", for other temperature ratings.	• La température de l'air ambiant 40 °C. Voir chapitre "Ambient Conditions", pour connaître les autres températures.
Use 75°C copper wire only, except for control circuits.	• Utiliser uniquement des fils de cuivre à 75°C, sauf pour les circuits de commande.
 Connector X3 torque requirements: screw terminals, tightening torque 18 in-lbs locking screw, tightening torque 3.5 in-lbs 	 Exigences de couple du connecteur X3: bornes à vis, couple de serrage 2 Nm vis de blocage, couple de serrage 0,35 Nm
 CAUTION Risk of Electrical Shock! Capacitors can have dangerous voltages present up to five minutes after switching off the supply power. For increased safety, measure the voltage in the DC bus link and wait until the voltage is below 50 V. 	ATTENTION: Risque de choc électrique! Des tensions dangereuses peuvent persister dans les condensateurs jusqu'à cinq minutes après la mise hors tension. Pour plus de sécurité, mesurez la tension dans la liaison de bus CC et attendez qu'elle soit inférieure à 50 V.

13.2 Conformance with EU

NOTE

Declarations of Conformity can be found on the Kollmorgen website.

The drives have been tested by an authorized testing laboratory in a defined configuration, using the system components that are described in this documentation. Any divergence from the configuration and installation described in this documentation means that the user will be responsible for carrying out new measurements to ensure conformance with regulatory requirements.

Kollmorgen declares the conformity of the product series Kollmorgen Essentials Drive with the following directives:

- EC Directive 2006/42/EU, Machinery Directive Used harmonized standard EN 61800-5-2
- EC Directive 2014/35/EU, Low Voltage Directive Used harmonized standard EN 61800-5-1
- EC Directive 2014/30/EU, EMC Directive Used harmonized standard EN 61800-3

NOTICE

These devices can cause high-frequency interferences in non industrial environments and may require measures for interference suppression (such as additional external EMC filters). Maximum distance for unshielded I/O lines is 3 m inside the cabinet. If the I/O cable leaves the cabinet, it must be EMC shielded.

13.2.1 Conformance with RoHS

The drives are manufactured in conformance with the directive 2011/65/EU of the European Parliament and of the Council of 8 June 2011 concerning the Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment (RoHS), including Commission Delegated Directive 2015/863/EUfor installation into Finished Electrical and Electronic Equipment (EEE). One or more exemptions per Annex III of Directive 2011/65/EU may be applicable.

The conformity is only valid on the delivery date.

The chemical composition of the product may change due to environmental influences.

13.2.2 Conformance with REACH

The servo drives are manufactured in conformance with the regulation (EC) 1907/2006 of the European Parliament and of the Council of 18 December 2006 concerning the Registration, Evaluation, Authorization and Restriction of Chemicals (REACH).

Based on Article 33, Paragraph (1), Kollmorgen communicates that the servo drives and articles used may contain substances listed in the Restriction List in Annex XVII in the allowed uses. The servo drives may contain substances listed in the Candidate List of Substances of Very High Concern (SVHC) as published by the European Chemical Agency on their official website.

The conformity is only valid on the delivery date.

The chemical composition of the product may change due to environmental influences.

13.3 Conformance with PFAS

Per- and polyfluoroalkyl substances (PFAS) is a group of manmade chemicals used to make fluoropolymer coatings and products that resist heat, oil, stains, grease, and water.

Fluoropolymer coatings can be in a variety of products. This can include clothing, furniture, adhesives, food packaging, heat-resistant non-stick cooking surfaces, and the insulation of electrical wire.

This device does contain perfluoroalkyl and polyfluoroalkyl substances, known as PFAS.

Please find the corresponding declaration on the Kollmorgen Website.

13.4 Conformance with CAL_Prop65

This device complies with the California's Safe Drinking Water and Toxic Enforcement Act of 1986, more commonly referred to as Proposition 65 ("Prop 65").

The device may contain one or more of the substances listed by the States of California Environmental Protection Agency Office of Environmental Health Hazard Assessment (OEHHA) as "chemical known to the State to cause cancer or reproductive toxicity". However, the presence of such chemicals in this device create no or negligible exposure to humans or the environment and such exposure.

Please find the corresponding declaration on the Kollmorgen Website.

13.5 Conformance with POP

The drives are manufactured in conformance with the Stockholm Convention. The drives do not contain Persistent Organic Pollutants (POP) listed in the annexes to the Regulation (EU) 2019/1021 and published by the European Chemical Agency on their official website.

Please find the corresponding declaration on the Kollmorgen Website.

13.6 Conformance with TSCA

The United States Environmental Protection Agency (EPA) has issued a rule, under Section 6(h) of the Toxic Substances Control Act (TSCA), which will phase out the use of 5 Persistent Bioaccumulative and Toxic (PBT) substances.

Kollmorgen does not intentionally add these substances to the products and the supply chain also confirms that they are not used.

Please find the corresponding declaration on the Kollmorgen Website.

13.7 Conformance with EtherCAT

The device is successfully EtherCAT Conformance Tested.

14 Index

A
Abbreviations 12, 108 Ambient Conditions 35 Aux. supply 24V, interface 69
C
Cable and Wire Requirements 49 Commissioning 111 Conformance
CAL_Prop65 133 CE 132 EtherCAT 133 PFAS 132 POP 133 REACH 132 RoHS 132 TSCA 133 UL, cUL 130 Connector Position 56
D
DC Bus Capacitance 39 DC bus link, interface 70 Decommission 25 Dimensions 44 Disassemble 26 Disposal 27 Document revisions 136 Dynamic Drive Braking 38
E
Emergency Off 21 Emergency Stop Function 21 Enclosure (FS) 109 EtherCAT 81 EtherNet/IP 83
F
Factury Default Setting 113 Fault messages 102 Functional Safety (FS) 104 Functional Safety 1 (FS1) 112 Fusing
24V supply 69 Mains supply 68
G Grounding 47 Grounding Plates 55
н
Hardware requirements WorkBench94

Industrial Ethernet Initial Drive Test Inputs	
Digital78, Installation	85
Electrical	
Mechanical	
Software WorkBenchInstallation, Setup, Normal Operation	
L	
Leakage current	.19
M	
Mains supply, interface	
Maintenance	
Mating Connectors Mechanical Data	
Motor Holding Brake Connection	
Motor interface	
Motor single cable connection	
N	
Nameplate	.29
0	
Operating systems WorkBench	94
P	
Package supplied Part Number Scheme	
PC connection	84
Product Safety	
PROFINET	. 82
Prohibited Use Functional Safety	107
General	
R	
REACH	132
Re-forming	
Regen circuit	
Regen resistor Regeneration Braking	
Repair	
RoHS	
S	
Safety	
Functional Safety	
Product Safety	
Safety FaultsSafety Instructions	ΙΙδ
Drive Setup	. 88

Electrical Installation	46
General	
Mechanical Installation	
Safety Properties	
Safety Warnings	
Service Interface	
Setup	
Setup Software	
Shield connection	
Shielding	
Shock-hazard protection	
Site	
STO	
Stop Function	
Switch-on, switch-off behavior	
Symbols used	10
Т	
Trouble Shooting	102
U	
UL Markings	131
Use as directed	
Drive	17
Functional Safety	
WorkBench Setup Software	93
V	
Vantilation	25
Ventilation	
Verification	111
W	
Warning Messages	102
Warning note labels	
Wiring	

15 Record of Document Revisions

Edition	Remarks
A, 10/2025	First edition
	Table with lifecycle information of this document (→ # 136)

16 Copyrights, Trademarks, Patents, and Disclaimers

Copyright © 2025 Regal Rexnord Corporation, All Rights Reserved.

Information in this document is subject to change without notice. The software package described in this document is furnished under a license agreement. The software package may be used or copied only in accordance with the terms of the license agreement.

This document is the intellectual property of Kollmorgen and contains proprietary and confidential information. The reproduction, modification, translation or disclosure to third parties of this document (in whole or in part) is strictly prohibited without the prior written permission of Kollmorgen.

Kollmorgen Trademarks

Regal Rexnord and Kollmorgen are trademarks of Regal Rexnord Corporation or one of its affiliated companies.

These trademarks or tradenames are owned by or under the control of Regal Rexnord Corporation or any of its affiliates:

- AKD
- AKM
- Kollmorgen Essentials
- SafeMotion

Other Trademarks

These trademarks or tradenames are **not** owned by or under the control of Regal Rexnord Corporation or any of its affiliates:

- EtherCAT, Beckhoff Automation GmbH.
- EtherNet/IP, ODVA, Inc.
- EtherNet/IP Communication Stack: copyright (c) 2009, Rockwell Automation.
- PROFINET, PROFIBUS Nutzerorganisation e.V.
- SIMATIC, Siemens Aktiengesellschaft (Joint Stock Company; Germany).
- · Windows, Microsoft Corporation.

Patents

Current patents

- US Patent 81,542,28 (Dynamic Braking For Electric Motors)
- US Patent 10,374,468 (System and method for improved DC power line communication)
- US Patent 10,520,050 (Method and apparatus for power-saving, fail-safe control of an electromechanical brake)
- US Patent 10,840,696 (Method and apparatus for limiting the output voltages of switch mode power supplies)

Patents referring to fieldbus functions are listed in the matching fieldbus manual.

Disclaimer

Technical changes which improve the performance of the device may be made without prior notice!

This document is the intellectual property of Kollmorgen Corporation ("Kollmorgen"). All rights reserved. No part of this work may be reproduced in any form (by photocopying, microfilm or any other method) or stored, processed, copied or distributed by electronic means without the written permission of Kollmorgen.

The information in this document is believed to be accurate and reliable at the time of its release. Kollmorgen assumes no responsibility for any damage or loss resulting from the use of this help, and expressly disclaims any liability or damages for loss of data, loss of use, and property damage of any kind, direct, incidental or

consequential, in regard to or arising out of the performance or form of the materials presented herein or in any software programs that accompany this document.

Support and Services

About Kollmorgen

When you need motion and automation systems for your most demanding applications and environments, count on Kollmorgen - the innovation leader for more than 100 years. We deliver the industry's highest-performing, most reliable motors, drives, AGV control solutions and automation platforms, with over a million standard and easily modifiable products to meet virtually any motion challenge. We offer manufacturing facilities, distributors and engineering expertise in all major regions around the world, so you can bring a better machine to market faster and keep it profitable for many years to come.

Kollmorgen Support Network



See the $\underline{\text{Kollmorgen Support Network}}$ for product support, product downloads, knowledge base answers, and information.



Kollmorgen Support Locations

North America Kollmorgen Corporation 201 West Rock Road Radford, VA 24141, USA

Web: www.kollmorgen.com

Email: kollmorgen.support@regalrexnord.com

Tel.: +1-540-633-3545 Fax: +1-540-639-4162

U-039-4102 Fax:

South America Altra Industrial Motion do Brasil Equipamentos Industriais Ltda. Avenida João Paulo Ablas, 2970

Jardim da Glória, Cotia – SP CEP 06711-250, Brazil

Web: www.kollmorgen.com

Email: kollmorgen.contato@regalrexnord.com

Tel.: (+55 11) 4615-6300

Europe Kollmorgen Eu

Kollmorgen Europe GmbH

Pempelfurtstr. 1

40880 Ratingen, Germany

Web: www.kollmorgen.com

Email: Technical.Support.EU@regalrexnord.com

Tel.: +49-2102-9394-0 **Fax:** +49-2102-9394-3155

China and SEA

A and S Industry Technology (Tianjin) Co., Ltd.

Room 302, Building 5, Libao Plaza, 88 Shenbin Road, Minhang District,

Shanghai, China.

Web: www.kollmorgen.cn

Email: Sales.China@regalrexnord.com

Tel.: +86-400 668 2802

